

# PART LIST - MODEL NO. WL401100

Rev. 6/90

Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Flywheel	34	2	Link Arm Bushing
2	1	Flywheel Plate	35	1	Spring Assembly
3	2	Bushing	36	1	Resistance Strap
4	4	Axle Nut	37	2	Link Arm
5	4	Flywheel Sprocket Bolt	38	2	Small Bushing
6	1	Spacer Nut	39	4	Stabilizer Endcap
7	1	Sensor Wire/Driver	40	1	Front Stabilizer
8	4	Axle Washer	41	4	Acorn Nut
9	2	Handlebar Endcap	42	4	Stabilizer Washer
10	2	Foam Handgrip	43	4	Carriage Bolt
11	1	Left Handlebar	44	1	Frame
12	2	Pedal Cap	45	1	Chain
13	5	Nut	46	2	Shaft Nut
14	2	Pedal Washer	47	1	Crank w/Sprocket
15	2	Pedal	48	1	Crank Pin
16	2	Pedal Shaft	49	1	Rear Stabilizer
17	1	Electronic Monitor	50	1	Seat Post Bolt
18	1	Right Handlebar	51	1	Seat Post Washer
19	1	Resistance Knob	52	1	Seat Knob
20	1	Resistance Knob Housing	53	1	Seat Post
21	1	Resistance Cable	54	1	Seat
22	2	Housing Screw	55	1	Waved Washer
23	1	Pivot Shaft	56	1	Flywheel Sprocket
24	6	Mounting Screw	57	1	Flywheel Axle
25	4	Small Handlebar Bushing	58	2	Inner Crank Bushing
26	2	Large Handlebar Bushing	59	2	Outer Crank Bushing
27	4	Handlebar Washer	60	1	Large Crank Washer
28	4	Handlebar Nut	61	1	Thin Nut
29	2	Side Shield	#	1	Owner's Manual
30	2	Hardened Washer	#	1	Monitor Operation Guide
31	1	Strap Buckle			
32	1	Strap Buckle Screw			
33	2	Shaft Washer			

Note: "#" indicates a non-illustrated part. Specifications are subject to change without notice. See the back cover for information on ordering replacement parts.

## Crank Assembly

