

# PART LIST - MODEL NO. WL402300

Rev 8/9


Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Seat Post	36	1	Frame
2	4	Seat Nut	37	1	Right Link Arm
3	1	Seat	38	2	Console Plate Screw
4	1	Seat Post Sleeve	39	1	Tension Buckle
5	4	Handlebar Endcap	40	1	Tension Buckle Screw
6	2	Foam Grip	41	2	Monitor Screw
7	4	Resistance Housing Screw	42	2	Link Arm Bushing
8	1	Console Plate	43	1	Left Link Arm
9	1	Resistance Knob (N/S) on 18	44	6	Fan Shield Screw
10	1	Electronic Monitor	45	1	Fan Shield Bracket
11	1	Thin Axle Nut	46	2	Cotter Pin
12	1	Axle Shaft	47	2	Adjustment Nut
13	1	Fan w/Sprocket	48	2	Adjustment Washer
14	1	Left Side Shield	49	2	Adjustment Bolt
15	2	Side Shield Screw	50	2	Shaft Nut
16	2	Bearing	51	4	Fan Shield Clip
17	1	Axle Spacer	52	4	Lock Nut
18	1	Resistance Housing	53	1	Seat Pin
19	2	Pedal Cap	54	2	Fan Shield
20	2	Pedal Nut	55	4	Stabilizer Cap
21	2	Washer	56	4	Carriage Bolt
22	2	Pedal	57	2	Stabilizer
23	2	Pedal Shaft	58	1	Right Side Shield
24	1	Monitor Plate	59	4	Self-Tapping Screw
25	2	Pedal Spring	60	1	Chain
26	2	Pedal Washer	61	1	Crank/Sprocket Assembly
27	1	Left Handlebar	62	1	Resistance Strap
28	6	Pivot Bushing	63	1	Spring Assembly
29	2	Foot Rest	64	1	Sensor Magnet
30	3	Axle Nut	65	1	Pulse Earclip
31	4	Axle Washer	66	1	Clothes Clip
32	1	Pivot Shaft	67	2	Pivot Shaft Lock Washer
33	1	Resistance Cable Assembly (N/S on 18)	68	2	Link Arm Washer
34	1	Sensor Wire/Reed Switch	69	2	Spring Washer
35	1	Right Handlebar	#	1	Owner's Manual
36	1	Frame	#	1	Monitor Operation Guide
			#	1	Phillips Tool
			#	2	Socket Tool
			70	2	Clevis pin

Note: "#" indicates a non-illustrated part. Specifications are subject to change without notice. See the back cover for information on ordering replacement parts.

# EXPLODED DRAWING - MODEL NO. WL402301

Rev. 4/91

Specifications are subject to change without notice.



Crank Assembly

