

# PART LIST - MODEL NO. WL402500

Rev. 7/90

Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Seat Post	38	2	Tension Motor Screw
2	4	Seat Nut	39	1	Tension Buckle
3	1	Seat	40	1	Tension Buckle Screw
4	1	Seat Post Sleeve	41	2	Link Arm Washer
5	4	Handlebar Endcap	42	2	Link Arm Bushing
6	2	Foam Grip	43	1	Left Link Arm
7	5	Plate Screw	44	6	Fan Shield Screw
8	1	Console Plate	45	1	Fan Shield Bracket
9	1	Programmable Console	46	2	Cotter Pin
10	1	Electronic Monitor	47	1	Adjustment Nut
11	1	Thin Axle Nut	48	1	Adjustment Washer
12	1	Axle Shaft	49	1	Adjustment Bolt
13	1	Fan w/Sprocket	50	2	Shaft Nut
14	1	Left Side Shield	51	4	Fan Shield Clip
15	2	Side Shield Screw	52	4	Acorn Nut
16	2	Bearing	53	1	Seat Pin
17	1	Axle Spacer	54	2	Fan Shield
18	10	Console Knob	55	4	Stabilizer Cap
19	2	Pedal Cap	56	4	Carriage Bolt
20	2	Pedal Nut	57	2	Stabilizer
21	10	Washer	58	1	Right Side Shield
22	2	Pedal	59	4	Self-Tapping Screw
23	2	Pedal Shaft	60	1	Chain
24	2	Shaft Washer	61	1	Crank/Sprocket Assembly
25	2	Pedal Spring	62	1	Resistance Strap
26	2	Pedal Washer	63	1	Spring Assembly
27	1	Left Handlebar	64	3	Sensor Magnet
28	6	Pivot Bushing	65	2	Power Plug Screw
29	2	Foot Rest	66	1	Power Plug
30	3	Axle Nut	67	1	Power Cord
31	4	Axle Washer	68	1	Tension Rope
32	1	Pivot Shaft	69	1	Right Link Arm
33	1	Wire Harness	#	1	Owner's Manual
34	1	Sensor Wire/Reed Switch	#	1	Monitor Operation Guide
35	1	Right Handlebar	#	1	Phillips Tool
36	1	Frame	#	2	Socket Tool
37	1	Tension Motor Assembly			

Note: "#" indicates a non-illustrated part. Specifications are subject to change without notice. See the back cover for information on ordering replacement parts.

# EXPLODED DRAWING - MODEL NO. WL402500

Rev. 7/90

Specifications are subject to change without notice.



Crank Assembly

