

PART LIST—Model No. WL420020

Rev. 8/92

Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Side Rail w/Foam Grip	44	1	Shock Cushion
2	2	Foam Grip	45	1	Incline Shock
3	13	Screw	46	1	Cotter Pin
4	1	Console Assembly	47	1	Shock Pin
5	1	Speed Control Knob	48	1	Right Foot Rail
6	1	Clothes Clip	49	1	U-Nut
7	1	Pulse Earclip	50	2	Swivel Shaft Bolt
8	1	Safety Key/Clip	51	3	Roller Adjustment Washer
9	1	Incline Lever	52	1	Front Roller Adjustment Bolt
10	1	Handrail Bolt	53	4	Hood Anchor
11	1	Upright Post	54	1	Safety Cover
12	2	Choke	55	1	Front Roller/Pulley
13	1	Controller	56	1	Walking Belt
14	1	Handrail w/Foam Grip	57	1	Walking Platform
15	1	Motor Ground Strap	58	1	Right High Density Foam
16	9	Side Rail Nut/Motor Nut	59	1	Frame
17	1	Motor	60	2	Rear Leg Endcap
18	1	Pulley/Flywheel/Fan	61	4	Leg Screw/Guard Screw
19	4	Motor Isolator	62	6	Platform Clamp Screw
20	1	Motor Mount Swivel Shaft	63	6	Platform Screw
21	4	Hood Screw	64	6	Platform Clamp
22	1	J-Bolt	65	6	Platform Clamp Bushing
23	1	Tension Washer	66	6	Small Bushing
24	1	Tension Spring	67	1	Right Endcap
25	1	J-Bolt Nut	68	2	Endcap Screw
26	3	Locknut	69	2	Rear Roller
27	1	Incline Cable	70	2	Roller Spacer
28	1	Upright Spacer	71	2	Roller Guard
29	1	Lock Knob Washer	72	3	Wire Clip
30	1	Lock Knob	73	1	Allen Wrench
31	2	Flat Washer	74	1	Wrench Clip
32	1	Pivot Bolt	75	1	Rear Roller
33	2	Ground Washer	76	1	Left Endcap
34	1	Grommet	77	1	Left Foot Rail
35	1	Power Cord	78	1	Motor Hood/Decal
36	1	Circuit Breaker	79	1	Side Rail Bolt
37	12	Plastic Fastener	80	1	Magnet
38	2	Front Wheel	81	1	Sensor Wire/Reed Switch
39	2	Wheel Bolt	82	1	Belt
40	1	Incline Leg	83	1	Left High Density Foam
41	2	Incline Leg Bolt	84	1	Front Roller Insert
42	1	Shock Release	85	1	Shock Bracket
43	1	E-Clip	#	1	Owner's Manual

Note: "#" indicates a non-illustrated part. Specifications are subject to change without notice. See the back cover for information about ordering replacement parts.

EXPLODED DRAWING—Model No. WL420020

Rev. 8/92