

# PART LIST—Model No. WL460020

Rev. 12/92

| Key No. | Qty. | Description                  | Key No. | Qty. | Description                 |
|---------|------|------------------------------|---------|------|-----------------------------|
| 1       | 1    | Left Handrail                | 46      | 1    | Frame                       |
| 2       | 2    | Long Handrail Bolt           | 47      | 8    | Motor Mount Nut             |
| 3       | 1    | Safety Key/Clip              | 48      | 1    | Motor Mount Plate           |
| 4       | 1    | Clothes Clip                 | 49      | 1    | Motor Pivot Bolt            |
| 5       | 1    | Pulse Earclip                | 50      | 4    | Motor Isolator              |
| 6       | 33   | Small Screw                  | 51      | 1    | Ground Strap                |
| 7       | 1    | Console Plate                | 52      | 1    | Motor                       |
| 8       | 1    | Console                      | 53      | 4    | Hood Anchor Screw           |
| 9       | 1    | Short Wire Harness           | 54      | 1    | Power Supply Board          |
| 10      | 1    | Handrail Wire Harness        | 55      | 1    | Mounting Plate              |
| 11      | 2    | Switch Bolt                  | 56      | 8    | Plastic Stand-Off           |
| 12      | 2    | Optic Switch                 | 57      | 1    | Pulley/Flywheel/Fan         |
| 13      | 1    | Incline Switch Bracket       | 58      | 1    | Cushion Knob                |
| 14      | 2    | Switch Nut                   | 59      | 4    | Cushion Spring Bolt         |
| 15      | 1    | Incline Bracket Screw        | 60      | 1    | Cotter Pin                  |
| 16      | 1    | Incline Optic Disk           | 61      | 1    | Incline Motor Pin           |
| 17      | 6    | Lock Nut                     | 62      | 2    | Cushion Spring/Foot         |
| 18      | 1    | Incline Motor                | 63      | 1    | Adjustment Rod              |
| 19      | 3    | Leg Bolt/Motor Bolt          | 64      | 2    | Cushion Cover               |
| 20      | 1    | Choke                        | 65      | 1    | Right Endcap                |
| 21      | 1    | Controller                   | 66      | 4    | Endcap Screw                |
| 22      | 1    | Right Handrail               | 67      | 1    | Allen Wrench                |
| 23      | 4    | Hood Anchor                  | 68      | 1    | Wrench Clip                 |
| 24      | 2    | Ground Washer                | 69      | 1    | Rear Roller                 |
| 25      | 1    | Grommet                      | 70      | 2    | Rear Roller Spacer          |
| 26      | 1    | Power Cord                   | 71      | 1    | Left Endcap                 |
| 27      | 1    | Circuit Breaker              | 72      | 6    | Platform Screw              |
| 28      | 2    | Frame Endcap                 | 73      | 8    | Foot Rail Washer            |
| 29      | 10   | Belly Pan Pin                | 74      | 2    | Rod Washer                  |
| 30      | 1    | Front Roller Adjustment Bolt | 75      | 2    | Retainer                    |
| 31      | 3    | Roller Adjustment Washer     | 76      | 1    | Rod Endcap                  |
| 32      | 2    | Front Wheel                  | 77      | 6    | Hood Screw/Foot Rail Screw  |
| 33      | 2    | Wheel Bolt                   | 78      | 1    | Motor Hood w/Decal          |
| 34      | 1    | Incline Leg                  | 79      | 4    | Short Handrail Bolt         |
| 35      | 2    | Belt Guide                   | 80      | 1    | Speed Optic Disk            |
| 36      | 4    | Handrail Washer              | 81      | 1    | Belt                        |
| 37      | 1    | Belly Pan                    | 82      | 2    | Rear Roller Adjustment Bolt |
| 38      | 1    | Carriage Bolt                | 83      | 1    | Speed Switch Bracket        |
| 39      | 2    | Flat Washer                  | 84      | 1    | Incline Control             |
| 40      | 1    | Tension Spring               | 85      | 1    | Bezel                       |
| 41      | 5    | Nut                          | 86      | 1    | Lift Board                  |
| 42      | 1    | Front Roller/Pulley          | 87      | 1    | Lift Board Plate            |
| 43      | 1    | Walking Platform             | 88      | 1    | Belly Pan Wire Harness      |
| 44      | 1    | Walking Belt                 | #       | 1    | Owner's Manual              |
| 45      | 2    | Foot Rail                    |         |      |                             |

Note: "#" indicates a non-illustrated part. Specifications are subject to change without notice. See the back cover for information about ordering replacement parts.

# EXPLODED DRAWING—Model No. WL460020

Rev. 12/92

