

PART LIST—Model No. WL611020

Rev. 6/92

Key No.	Qty.	Description	Key No.	Qty.	Description
1	2	Ski Rail	19	1	Resistance Dial
2	1	Rear Stabilizer	20	1	Housing Cap
3	4	Stabilizer Endcap	21	1	Long Bolt
4	2	Ski Pedal	22	8	Roller Bolt
5	2	Pulley	23	8	Ski Pedal Roller
6	1	Resistance Strap	24	1	Right Ski Pole
7	2	Pulley Bolt	25	1	Left Ski Pole
8	11	Nut	26	1	Upright
9	8	Screw	27	1	Electronic Monitor
10	8	Stabilizer Screw	28	2	Foam Grip
11	2	Ski Pole Endcap	29	2	Ski Pole Housing
12	2	Magnet Screw	30	8	Resistance Pad
13	8	Roller Spacer	31	1	Upright Housing
14	1	Magnet	32	2	Adhesive Strip
15	1	Monitor Wire	33	2	Ski Pedal Cover
16	1	Resistance Knob	34	2	Pulley Washer
17	1	Front Stabilizer	35	1	Reed Wire/Switch
18	2	Nylon Washer	#	1	Owner's Manual
			#	1	Grease

Note: "#" indicates a non-illustrated part. Specifications are subject to change without notice. See the back cover for information about ordering replacements parts.

EXPLODED DRAWING—Model No. WL611020

Rev. 6/92

