


Key No.	Qty.	Description	Key No.	Qty.	Description
1	2	Axle Nut	31	2	Adjustment Bolt
2	4	8mm x 16mm Black Washer	32	2	Steel Link Arm Bushing
3	1	Spacer	33	4	Curved Washer
4	1	Axle Spacer	34	2	Stabilizer
5	1	Fan Axle	35	4	Stabilizer Endcap
6	2	Flange Bushing	36	4	8mm x 40mm Carriage Bolt
7	1	Fan Assembly	37	2	Fan Guard
8	4	Handlebar Endcap	38	1	Right Handlebar
9	2	Foam Grip	39	1	Crank/Sprocket Assembly
10	1	Left Handlebar	40	1	Seat
11	2	Pedal	41	1	Seat Post
12	8	8mm Black Locknut	42	5	8mm Zinc Locknut
13	2	8mm x 16mm Zinc Washer	43	2	5/16" Zinc Washer
14	2	Outer Pivot Bushings	44	1	Seat Post Bushing
15	1	Left Side Shield	45	1	Seat Pin
16	2	Side Shield Screw	46	1	Frame
17	1	Pivot Shaft	47	1	Sensor Wire/Reed Switch
18	2	Pedal Cap	48	1	Sensor Magnet
19	1	Electronic Monitor	49	4	Fan Guard Clip
20	1	Adhesive Block	50	6	Fan Guard Screw
21	4	Star Washer	51	1	Right Side Shield
22	2	1/2" Zinc Locknut	52	1	Chain
23	2	9/16" Zinc Washer	53	3	3/4" Flat Washer
24	2	Pedal Axle	54	1	Fan Guard Bracket
25	2	Fan Bearing	55	4	Self-Tapping Screw
26	2	Link Arm	56	2	Pedal Spacer
27	2	Brass Handlebar Bushing	57	1	Fan Plate
28	4	Inner Pivot Bushing	58	3	1 1/4" Plate Screw
29	2	Adjustment Nut	59	1	Fan Sprocket
30	2	Formed Washer	#	1	Owner's Manual

Note: "#" indicates a non-illustrated part. Specifications are subject to change without notice. See the back cover of this manual for information about ordering replacement parts.

EXPLODED DRAWING—Model No. WL620030

Rev. 7/93



Crank Assembly

39

