

# PART LIST—Model No. WL740030

Rev. 9/93

Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Console	38	2	Pedal Arm
2	1	Pulse Earclip	39	8	Pedal Arm Bushing
3	1	Power Key	40	2	Pedal Arm Pushnut
4	4	Screw	41	2	Pedal Arm Spacer
5	1	Console Plate	42	2	Link Arm
6	1	Frame	43	4	Link Arm Bushing
7	1	Tension Buckle	44	4	Link Arm Pushnut
8	2	Large Bumper	45	2	Clevis Pin
9	1	Tension Strap	46	2	Cotter Pin
10	1	Spring Assembly	47	1	Left Pedal
11	1	Tension Rope	48	1	Right Pedal
12	1	Tension Motor	49	2	Pulley Bushing
13	2	Tension Motor Screw	50	1	Power Plug Screw
14	2	Snap Ring	51	2	Mounting Screw
15	2	Large Sprocket Washer	52	1	Power Cord
16	2	Sprocket Key	53	1	Pulley Nut
17	2	Small Sprocket	54	1	Reed Switch
18	1	Small Sprocket Washer	55	1	Wire Harness
19	1	Large Sprocket	56	2	Small Bumper
20	1	Large Sprocket Chain	57	2	Console Bolt
21	1	Sprocket Spacer Cup	58	1	Left Handrail
22	2	Sprocket Bearing	59	1	Right Handrail
23	1	Spacer	60	1	Front Stabilizer
24	1	Flywheel Washer	61	6	Side Shield Screw
25	2	Thin Nut	62	1	Rear Stabilizer
26	2	Beveled Washer	63	4	Carriage Bolt
27	1	Flywheel Axle	64	2	Handrail Mounting Bolt
28	2	Flywheel Bearing	65	4	Stabilizer Nut
29	1	Flywheel Sprocket	66	4	Stabilizer Endcap
30	1	Flywheel	67	1	Left Side Shield
31	2	Small Flywheel Washer	68	3	Side Shield Bolt
32	2	Thick Nut	69	3	Side Shield Nut
33	2	Large Chain	70	1	Right Side Shield
34	1	Pulley Cable	71	1	Cable Guide
35	1	Pulley	72	1	Pulley Bolt
36	3	Magnet	#	1	Owner's Manual
37	4	Master Link			

Note: "\*" indicates a non-illustrated part. Specifications are subject to change without notice. See the back cover for information about ordering replacement parts.

# EXPLODED DRAWING—Model No. WL740030

Rev. 9/93

