

# PART LIST—Model No. WL800620/WL801020

Rev. 9/92

Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Top Upright	33	2	Press Arm Bolt
2	1	Bottom Upright	34	1	Right Butterfly Arm
3	1	Base	35	1	Left Butterfly Arm
4	1	Stabilizer	36	2 (3)	Large Pad
5	1	Right Pedal Assembly	37	4	Weightband
6	1	Left Pedal Assembly	38	4	Small Weightband Bushing
7	10 (14)	Nylock Nut	39	4	Large Weightband Bushing
8	4 (8)	Bench/Seat Screw	40	1	Leg Lever
9	6 (10)	Small Washer	41	2	Leg Lever Endcap
10	1	Bench Rail	42	2	Leg Lever Pad
11	1	Bench Leg	43	1	Leg Lever Pin
12	1	Bench	44	1	Hairpin Cotter Pin
13	2	Bench Leg Endcap	45	1 (2)	Foam Pad Tube
14	2	Bench Bolt	46	2 (4)	Foam Pad
15	3	Pull Pin	47	6 (8)	Large Spring Clip
16	2	Resistance Cylinder	48	1	Small Spring Clip
17	2	Resistance Cyl. Bushing Set	49	2	Bench Rail Bolt
18	2	Small Pushnut	#	1	Owner's Manual
19	2	Large Pushnut	#	1	Exercise Guide
20	2	Pedal Bushing Set			
21	2	Small Spacer			
22	2	Large Spacer			
23	2	Foot Pad			
24	4	Carriage Bolt	50	1	Ab Seat Leg
25	3	Base Endcap	51	1	Ab Seat Rail
26	10 (14)	Washer	52	1	Ab Arm
27	2	Upright Bolt	53	2	Ab Axle Cap
28	2	Weightband Tube	54	1	Ab Axle
29	1	Press Arm Pin	55	1	Ab Seat
30	1	Press Arm	-56	2	Ab Seat Leg Bolt
31	1	Press Bar	57	2	Ab Rail Bolt
32	2	Press Arm Nut			

## WL801020 (3XT) ONLY

Note: "#" indicates a non-illustrated part. Numbers in parentheses indicate quantities for the WL801020. Specifications are subject to change without notice. See the back cover of this manual for information about ordering replacement parts.

