

PART LIST—Model No. WLCR96050

R0895A

Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Monitor	29	*11	1/2" Dome Cap
2	1	Handlebar	30	6	1/2" Push Nut
3	1	Seat	31	1	1/2" x 3 3/4" Rod
4	1	Link Arm	32	1	Pedal Frame
5	1	Seat Frame	33	4	Roller
6	1	Frame	34	1	Spring
7	1	Handlebar Frame	35	1	Seat Adjust Bracket
8	4	Round Endcap	36	2	Slide Bushing
9	1	Resistance Cylinder	37	4	1/4" Nut
10	4	1 1/4" x 1 1/4" Endcap	38	1	Seat Knob
11	1	1 1/2" x 2" Endcap	39	1	1/2" x 6 1/2" Rod
12	2	Pedal	40	2	3/4" x 1 1/4" Spacer
13	2	Domed Endcap	41	2	1/4" Washer
14	2	Bumper	42	2	1/4" Screw
15	1	Reed Switch/Sensor Wire	43	2	Bushing
16	*4	#8 x 1/2" Screw	44	1	1/2" x 3 3/8" Rod
17	2	#8 x 1/2" Hex Head Screw	45	2	Spring Spacer
18	1	#8 x 3/4" Screw	46	2	#8 Washer
19	1	Center Link Arm	47	2	1/2" Link Arm Bushing
20	1	Handle	48	4	1/4" Plug
21	1	1/2" x 9 7/8" Pivot Rod	49	1	3/8" Plug
22	2	1/2" x 3" Rod	50	1	1/2" x 5/8" Bumper
23	2	1/2" Cylinder Bushing Set	#	1	User's Manual
24	2	.925" ABS Spacer	#	1	Pedal Tool
25	8	1/2" Bushing			
26	1	Foam Pad			
27	1	Magnet/Retainer			
28	1	1/2" x 5 3/4" Rod			

* One extra #8 x 1/2" Screw and one extra 1/2" Dome Cap may have been included.

Note: "*" indicates a non-illustrated part. Specifications are subject to change without notice. See the back cover of this manual for information about ordering replacement parts.

EXPLODED DRAWING—Model No. WLCR96050

R0895A

