

PART LIST—Model No. WLEL7397.1

R0108A

Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Frame	39	4	M6 Arc Washer
2	1	Front Stabilizer	40	2	M8 x 2 1/2" Shoulder Hex Bolt
3	1	Upright	41	4	M8 x 1 9/16" Hex Bolt
4	1	Left Pedal Tube	42	2	M8 x 3 3/8" Hex Bolt
5	1	Left Handlebar Leg	43	1	M8 x 2 3/8" Hex Bolt
6	2	Handlebar	44	1	M8 x 2 3/8" Tap Hex Bolt
7	1	Flywheel	45	6	M8 x 5/8" Hex Bolt
8	1	Left Pedal	46	4	M6 x 5/8" Pocket Screw
9	1	Flywheel Axle	47	10	M5 x 5/8" Pocket Screw
10	1	"C"-magnet	48	5	M4 x 1 9/16" Pocket Screw
11	2	Upright Spacer	49	1	M5 x 1 1/4" Screw
12	1	Resistance Control/Cable	50	4	Wave Washer
13	2	Handlebar Endcaps	51	2	M8 x 3 1/2" Carriage Bolt
14	1	Drivr Wheel Assembly	52	5	M8 Washer
15	1	Right Crank Arm	53	4	M10 Washer
16	2	Plastic Sleeves	54	8	M8 Arc Washer
17	8	Handlebar Bushing	55	2	M6 Washer
18	1	Spring	56	8	M6 Nylon Locknut
19	2	Foam Handle Grip	57	7	M8 Nylon Locknut
20	1	Rear Stabilizer	58	1	M10 Nylon Locknut
21	1	Left Side Shield	59	1	M8 Hex Nut
22	1	Console	60	1	Magnet
23	4	Leg Bushing	61	2	M3 x 1/2" Pocket Screw
24	2	M8 Cap Nut	62	2	M10 Spacer
25	1	Left Disc Cover	63	1	Right Pedal
26	4	M8 x 3/4" Hex Bolt	64	1	Right Pedal Tube
27	2	Bearing Cover	65	1	Right Side Shield
28	2	Rear Stabilizer Endcap	66	1	Right Disc Cover
29	2	Transport Wheel	67	1	Reed Switch/Wire
30	1	Drive Belt	68	5	Console Screw
31	2	Plastic Washer	69	1	Reed Switch Bracket
32	4	Nylon Bushing	70	1	Lower Cable
33	2	Flywheel Bearing	71	1	Right Handlebar Leg
34	2	Crank Bearing	72	2	Pulse Sensor
35	2	Pedal Tube Endcap	73	2	Pulse Screw
36	1	"C"-clip	74	1	Pulse Wire
37	2	Eyebolt	75	1	Upper Wire
38	2	Adjustment Bracket	*	—	User's Manual

Note: Specifications are subject to change without notice. See the back cover of this manual for information about ordering replacement parts. *These parts are not illustrated.

EXPLODED DRAWING—Model No. WLEL7397.1

R0108A

