

PART LIST—Model No. WLMC00344

R0695A

Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Monitor	18	1	#8 x 3/4" Screw
2	1	Handlebar	19	4	1/2" Link Arm Bushing
3	1	Seat	20	4	3/8" Spacer
4	2	Link Arm	21	1	1/2" x 11 1/4" Pivot Rod
5	1	Seat Tube	22	1	1/2" x 3 1/2" Rod
6	1	Frame	23	2	1/2" Cylinder Bushing Set
7	1	Pedal Frame	24	2	15/16" Spacer
8	4	Endcap	25	6	1/2" Bushing
9	1	Resistance Cylinder	26	2	Foot Peg Foam
10	2	1 1/4" x 1 1/4" Endcap	27	1	Magnet/Retainer
11	1	1 1/2" x 2" Endcap	28	1	1/2" x 5 1/2" Rod
12	2	Pedal	29	10*	1/2" Dome Cap
13	2	1 1/4" x 2" Endcap	30	2	1/2" Push Nut
14	1	Bumper	31	1	1/2" x 4" Rod
15	1	Reed Switch/Sensor Wire	#	1	Owner's Manual
16	5*	#8 x 1/2" Screw	#	1	3/4" x 1" Pedal Tool
17	2	1/4" x 2" Screw			

*Note: One extra #8 x 1/2" Screw and 1/2" Dome Cap may have been included.

Note: "#" indicates a non-illustrated part. Specifications are subject to change without notice. See the back cover of this manual for information about ordering replacement parts.

EXPLODED DRAWING—Model No. WLMC00344

R0895A

