

PART LIST—Model No. WLMC00540

R1094A

Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Monitor	17	2	1/4" x 2" Screw
2	1	Handlebar	18	2	1/4" x 5/8" Screw
3	1	Seat	19	4	1/2" Link Arm Bushing
4	2	Link Arm	20	2	3/8" Spacer
5	1	Seat Tube	21	1	1/2" x 11 1/4" Pivot Rod
6	1	Frame	22	1	1/2" x 3 1/2" Rod
7	1	Pedal Frame	23	2	1/2" Thin Wall Bushing
8	4	Endcap	24	2	1/2" Push Nut
9	2	Foot Peg Foam	25	6	1/2" Thick Wall Bushing
10	2	1 1/4" x 1 1/4" Endcap	26	2	5/16" Washer
11	1	1 1/2" x 2" Endcap	27	1	Magnet/Retainer
12	2	Pedal	28	1	1/2" x 5 1/2" Rod
13	2	1 1/4" x 2" Endcap	29	4	1/2" Dome Cap
14	1	Bumper	30	2	Handlebar Endcap
15	1	Reed Switch/Sensor Wire	#	1	Owner's Manual
16	6	#8 x 1/2" Screw	#	1	3/4" x 1" Pedal Tool

Note: "#" indicates a non-illustrated part. Specifications are subject to change without notice. See the back cover of this manual for information about ordering replacement parts.

