

PART LIST—Model No. WLMC01450

R1295A

Key No.	Qty.	Description	Key No.	Qty.	Description
1	6	1/4" Nylon Locknut	22	1	Seat
2	8	1/4" x 1" Screw	23	1	Backrest
3	4	1/4" x 2" Bolt	24	1	Lock Pin
4	1	Base	25	2	1 3/4" Pin
5	2	3" x 1" Endcap	26	1	3 3/8" Pin
6	4	2" Round Endcap	27	2	#25 Weight Band
7	8	1/2" Axle Cap	28	1	#10 Weight Band
8	4	3/4" Endcap	29	1	#5 Weight Band
9	4	1 1/2" Endcap	30	4	3/8" Washer
10	6	1/2" Bushing	31	2	1/2" Bushing
11	1	Seat Frame	32	4	Spring Clip
12	1	Seat Bushing	33	2	3/8" x 2 1/4" Carriage Bolt
13	1	Left Arm	34	2	3/8" Nylon Locknut
14	1	Right Arm	35	2	Large Pad
15	2	Small Pad	36	2	1 1/2" Foam Grip
16	1	Pivot Arm	37	2	3" x 1" Outer Endcap
17	2	1 1/4" Foam Grip	38	1	"L"-Pin
18	1	Leg Lever	39	1	Pivot Plate
19	1	Backrest Frame	40	2	1/2" Weld Spacer
20	1	Crunch Handle	#	1	Allen Wrench
21	1	Slotted "U"-Bracket	#	1	User's Manual

Note: "#" indicates a non-illustrated part. Specifications are subject to change without notice. See the back cover for information about ordering replacement parts.

EXPLODED DRAWING—Model No. WLMC01450

R1295A

