

PART LIST—Model No. WLST77540

R894A

Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Programmable Console	33	4	1/4" Nylock Nut
2	1	Frame	34	1	Motor Gear
3	1	Right Side Shield	35	1	Motor ✓
4	3	Side Shield Bolt	36	2	#4 x 3/4" Screw
5	6	Side Shield Screw	37	1	Front Stabilizer
6	3	Side Shield Nut	38	1	Rear Stabilizer
7	1	Console Plate	39	4	Stabilizer Endcap
8	4	Screw	40	4	5/8" Cylinder Bushing
9	2	Console Bolt	41	2	5/8" Push Washer
10	1	Right Handrail	42	4	Stabilizer Nut
11	1	Left Handrail	43	4	Link Arm Bushing
12	1	Wire Harness	44	6	Link Arm Pushnut
13	2	Handrail Foam	45	2	Pedal Arm Spacer
14	1	Gear Box	46	8	Pedal Arm Bushing
15	1	Power Cord	47	2	3/4" Pedal Arm Axle Cap
16	1	Side Shield Cap	48	4	3 1/2" Screw
17	1	Left Side Shield	49	2	Pedal Arm
18	2	Pulley	50	1	Magnet/Clamp
19	2	Cable	51	2	Clevis Pin
20	2	1 3/4" Screw	52	2	Cotter Pin
21	4	3/8" Cylinder Bushing	53	2	Bumper
22	2	3/8" Washer	54	2	Link Arm
23	4	3/8" Nylock Nut	55	2	Pedal
24	2	Resistance Cylinder	56	1	Reed Switch/Sensor Wire
25	2	3/8" Pushnut	57	1	Power Plug
26	4	1/2" Screw	58	2	Link Arm Axle
27	2	Cylinder Clamp	59	1	Pulley Axle
28	4	Carriage Bolt	60	2	#10 Nylock Nut
29	4	1/4" Flat Washer	61	1	Wire Harness Pigtail
30	6	#10 x 1" Screw	62	2	Pedal Stop
31	6	Flat Washer	#	1	Owner's Manual
32	4	Rubber Washer			

Note: "#" indicates a non-illustrated part. Specifications are subject to change without notice. See the back cover for information about ordering replacement parts.

EXPLODED DRAWING—Model No. WLST77540

R894A

