

PART LIST—Model No. WLTL15050

R795A

Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Left Upper Body Arm	39	2	Frame Cap
2	1	Right Upper Body Arm	40	1	Left End Cap
3	1	Hairpin Cotter	41	1	Right End Cap
4	8	Platform Screw	42	2	Rear Roller Adjustment Bolt
5	8	Screw	43	2	Adjustment Plate
6	10	#8 Finish Washer	44	2	Foam Grip
7	1	Console	45	1	Walking Belt
8	1	Walking Platform	46	1	Friction Cover
9	2	Incline Leg	47	1	Pivot Bolt
10	1	Upright	48	1	Control Washer
11	1	Lock Pin	49	2	Belt Guide
12	1	Flywheel Shaft	50	1	Wrench Clip
13	2	Eye Bolt	51	1	Magnet
14	1	Hood	52	1	Pad Knob
15	1	Arm Resistance Control	53	1	Allen Wrench
16	2	Friction Bracket	54	1	Cable Tie
17	5	Washer	55	2	Arm Cap
18	2	Upper Body Arm Housing	56	1	E-Ring
19	2	Friction Plate	57	1	Speed Control
20	2	Side Trim	58	1	Cable Tie Clip
21	10	#8 Flat Head Screw	59	1	Resistance Clamp Screw
22	2	Rear Foot	60	1	Resistance Clamp
23	4	Rear Foot Screw	61	1	Cable Adjustment Screw
24	1	Upright Bolt	62	2	Cable Adjustment Nut
25	1	Upright Flat Washer	63	1	Cable Clamp Bolt
26	2	Incline Pin	64	4	Cable Clamp Washer
27	1	Front Roller	65	1	Cable Clamp Nut
28	1	Rear Roller	66	1	Resistance Spring
29	1	Reed Switch/Sensor Wire	67	1	Resistance Belt
30	2	Flywheel Bearing	68	2	Incline Wheel Nut
31	1	Star Washer	69	2	Incline Wheel Bolt
32	1	Cage Nut	70	2	Incline Wheel
33	1	Abdominal Pad	71	1	Belt Resistance Cable
34	1	Flywheel	72	1	Abdominal Pad Extension
35	1	Flywheel Belt	73	2	Abdominal Pad Bolt
36	2	Retainer	74	2	Abdominal Pad Washer
37	1	Frame	75	1	Reed Switch Screw
38	2	Nut	#	1	User's Manual

Note: “#” Indicates a non-illustrated part. Specifications are subject to change without notice. See the back cover of this manual for information about ordering replacement parts.

EXPLODED DRAWING—Model No. WLTL15050

R795A

