

PART LIST—Model No. WLTL70040

R1194A

Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Left Upright/Handrail	56	1	Frame
2	2	Upright Endcap	57	2	Cushion Foot Cover
3	2	3/8" x 2" Bolt	58	2	Small Nut
4	4	Cage Nut	59	2	Optic Switch. - 102955
5	1	Console Crossbar	60	2	Small Bolt
6	1	Wire Cover	61	1	Incline Optic Disk
7	11	Console Screw	62	1	Incline Motor Bracket
8	1	Upright Wire Harness	63	2	Incline Motor Bolt
9	1	Console	64	1	Incline Motor
10	1	Safety Key/Clip	65	1	Incline Motor Spacer
11	1	Pulse Earclip/Clothes Clip	66	2	Optic Switch Wire Harness
12	1	7/32" Allen Wrench	67	6	Rear Endcap Screw/Knob Screw
13	1	24" Cable Loom	68	4	Cushion Foot Bolt
14	1	Right Upright/Handrail	69	2	Cushion Foot
15	1	Front Left Endcap	70	1	Right Rear Endcap
16	1	Front Roller/Pulley	71	2	Rear Roller Adjustment Bolt
17	1	Front Roller Adjustment Bolt	72	1	Cable Tie
18	3	Roller Adjustment Washer	73	4	4" Cable Tie
19	1	Front Right Endcap	74	3	8" Cable Tie
20	4	Flat Washer	75	1	Tie Block
21	4	3/8" x 3 1/2" Bolt	76	1	3/16" Allen Wrench
22	1	14" Power Board-Controller Wire	77	1	Wrench Clip
23	1	Belt Guide	78	1	Rear Roller
24	23	Safety Cover Screw	79	1	Left Rear Endcap
25	9	Screw	80	8	Platform Screw
26	2	6" Cable Loom	81	1	Left Foot Rail
27	1	20" Wire Harness	82	2	Star Washer
28	2	Upright Spacer	83	1	Choke Bracket
29	1	Electronics Bracket	84	1	Choke
30	7	Electronics Screw	85	1	Pivot Bolt
31	1	Grommet	86	1	Motor Tension Nut
32	1	Circuit Breaker	87	1	Motor Mount Bracket
33	1	On/Off Switch	88	1	Pulley/Flywheel/Fan
34	1	Power Cord	89	1	Motor Belt
35	2	Front Wheel Bolt	90	2	Motor Bolt
36	2	Front Wheel	91	1	Motor
37	1	Power Cord Bracket	92	2	Motor Nut
38	2	Foot Rail Track	93	1	Speed Optic Disk
39	1	Controller	94	1	Optic Switch Bracket
40	1	Safety Cover Bracket	95	1	Optic Switch Bracket Nut
41	6	Wheel Nut/Cushion Foot Nut	96	1	Cushion Knob
42	3	Incline Leg Bolt/Motor Tension Bolt	97	2	Cushion Foot Insert
43	3	3/8" Washer	98	1	Rod Endcap
44	5	Incline Leg Nut/Motor Swivel Nut	99	2	Rod Sleeve
45	1	Incline Leg	100	1	Cushion Foot Rod
46	1	Power Board	101	2	Deck Shim
47	4	Power Board Bolt	102	2	Crossbar Cage Nut
48	4	Power Board Spacer	#	1	8" White Wire, Male/Female
49	1	Console Plate	#	1	14" White Wire, 2 Female
50	2	Safety Cover Washer	#	1	4" Black Wire, 2 Female
51	1	Front Safety Cover	#	1	8" Black Wire, 2 Female
52	1	Rear Safety Cover	#	1	8" Green Ground Wire
53	1	Right Foot Rail	#	1	8" Red Wire, Male/Female
54	1	Walking Belt	#	1	8" Blue Wire, 2 Female
55	1	Walking Platform	#	1	Owner's Manual

Note: "#" indicates a non-illustrated part. Specifications are subject to change without notice. See the back cover for information about ordering replacement parts.

EXPLODED DRAWING—Model No. WLTL70040

R1194A

