

# PART LIST—Model No. WLTL84540

R794A

Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Left Handrail	41	1	Front Safety Cover
2	2	Upright Cap	42	1	Back Safety Cover
3	10	Cage Nut	43	1	Walking Belt
4	2	Console Bolt	44	1	Rear Leg Pad
5	1	Pulse Earclip/Clothes Clip	45	2	Shock Pin
6	1	Safety Key/Clip	46	1	Incline Shock Bracket
7	1	Console	47	2	Cotter Pin
8	1	Speed Control Knob	48	2	Incline Shock Spacer
9	1	Power Switch Wire	49	1	Incline Shock
10	1	Console Plate	50	1	Shock Release
11	1	6" Cable Loom	51	1	Incline Control Cable
12	14	Screw	52	3	8" Cable Tie
13	1	Right Handrail	53	2	4" Cable Tie
14	1	12" Cable Loom	54	1	Right Upright
15	4	Handrail Bolt	55	4	Right Rear Endcap
16	1	Front Roller Adjustment Bolt	56	2	Rear Roller Adjustment Bolt
17	3	Roller Adjustment Washer	57	1	Allen Wrench
18	1	Incline Control Lever	58	2	Wrench Clip
19	1	Front Left Endcap	59	1	Rear Roller
20	1	Right Foot Rail	60	1	Left Rear Endcap
21	6	Upright Washer	61	8	Platform Screw
22	4	Upright Bolt	62	1	Walking Platform
23	1	Strain Relief	63	1	Left Foot Rail
24	1	Belt Guide	64	1	Shock Spacer
25	1	Electronics Mounting Bracket	65	1	Motor Tension Bolt
26	1	Power Cord Grommet	66	5	Flat Washer
27	1	Circuit Breaker	67	1	Motor Mount Bracket
28	1	Power Cord	68	1	Left Upright
29	4	Wire Clip	69	1	Pulley/Flywheel/Fan
30	1	Circuit Breaker	70	1	Belt
31	2	Front Wheel	71	2	Motor Bolt
32	2	Front Wheel Bolt	72	1	Motor
33	2	Incline Leg Bolt	73	2	Motor Nut
34	2	Incline Leg Nut	74	1	Motor Swivel Bolt
35	2	Wheel Nut	75	1	Front Roller/Pulley
36	1	Incline Leg	76	1	Reed Switch/Sensor Wire
37	1	Choke	77	1	Reed Switch Extension Wire
38	4	Rear Endcap Screw	78	1	Front Left Endcap
39	15	Safety Cover Screw	#	1	Owner's Manual
40	1	Frame			

Note: "\*" indicates a non-illustrated part. Specifications are subject to change without notice. See the back cover for information about ordering replacement parts.

# EXPLODED DRAWING—Model No. WLT84540

R794A

