


WEIDER® *Weight Plate Storage Rack*

⚠ WARNING: To reduce the risk of serious injury, read the following precautions before using the rack.

1. Inspect and tighten parts often. Replace worn parts immediately.
2. Keep children under the age of 12 and pets away from the rack at all times.
3. The rack is intended for home use only. Do not use the rack in a commercial, rental, or institutional setting.
4. The rack is designed to support a maximum 210 pounds of weights (not included).
5. Locate the warning decal on the rack, and read the warnings before using the rack.
6. Use the rack only on a level surface. Cover the floor beneath the rack to protect the floor.



CUSTOMER HOT LINE:
1-800-322-2211
Mon.–Fri., 6 a.m.–6 p.m. MST

If you have questions, or if there are missing parts, PLEASE CALL DIRECT TO OUR TOLL-FREE CUSTOMER HOT LINE. The trained technicians on our customer hot line will provide immediate assistance.


Assembly Instructions

1. Attach a Bottom Tube (2) to each end of the Bottom Frame (3) with two M8 x 40mm Bolts (5) and two M8 Nylon Locknuts (6).
2. Attach the Front Upright (10) to the Bottom Frame (3) with two M8 x 40mm Bolts (5) and two M8 Nylon Locknuts (6). Slide the Outer Cap (8) onto the top of the Front Upright.
3. Slide the top of the Rear Upright (1) into the other side of the Outer Cap (8). Attach the Rear Upright to the Bottom Frame (3) with two M8 x 40mm Bolts (5) and two M8 Nylon Locknuts (6).
4. Screw a Weight Tube (4) onto each of the six posts on the Uprights (1, 10) and the Bottom Frame (3).
5. Insert the 25mm x 50mm Inner Caps (7) into the ends of the Bottom Tubes (2). Insert the 25mm Round Inner Caps (9) into the ends of the Weight Tubes (4).

⚠ WARNING

- Misuse of this product may result in serious injury.
- Read user's manual and follow all warnings and operating instructions prior to use.
- Do not allow children on or around machine.
- Replace label if damaged, illegible, or removed.

Designed and distributed by
WEIDERCARE,
a division of
ICON Health & Fitness, Inc.




Note: The warning decal shown at the left is found on the rack. If the decal is missing, call our Customer Service Department toll-free at 1-800-322-2211, Mon.–Fri., 6 a.m.–6 p.m., MST, to order a free replacement decal.

Part List/Exploded Drawing — Model No. RACKSTT

R1000A

Key No.	Qty.	Description
1	1	Rear Upright
2	2	Bottom Tube
3	1	Bottom Frame
4	6	Weight Tube
5	8	M8 x 40mm Bolt
6	8	M8 Nylon Locknut
7	4	25mm x 50mm Inner Cap
8	1	Outer Cap
9	6	25mm Round Inner Cap
10	1	Front Upright



To order replacement parts, simply call our Customer Service Department toll-free at 1-800-322-2211, Monday through Friday, 6 a.m. until 6 p.m. Mountain Time (excluding holidays). To help us assist you, please be prepared to give the following information:

- The MODEL NUMBER of the product (RACKSTT)
- The NAME of the product (Weight Plate Storage Rack)
- The KEY NUMBER and DESCRIPTION of the part(s) from the Part List and Exploded Drawing.

Limited Warranty

ICON Health & Fitness, Inc. (ICON), warrants this product to be free from defects in workmanship and material, under normal use and service conditions, for a period of ninety (90) days from the date of purchase. This warranty extends only to the original purchaser. ICON's obligation under this warranty is limited to replacing or repairing, at ICON's option, the product at one of its authorized service centers. All products for which warranty claim is made must be received by ICON at one of its authorized service centers with all freight and other transportation charges prepaid, accompanied by sufficient proof of purchase. All returns must be pre-authorized by ICON. This warranty does not extend to any product or damage to a product caused by or attributable to freight damage, abuse, misuse, improper or abnormal usage or repairs not provided by an ICON authorized service center, to products used for commercial or rental purposes, or to products used as store display models. No other warranty beyond that specifically set forth above is authorized by ICON.

ICON is not responsible or liable for indirect, special or consequential damages arising out of or in connection with the use or performance of the product or damages with respect to any economic loss, loss of property, loss of revenues or profits, loss of enjoyment or use, costs of removal, installation or other consequential damages of whatsoever nature. Some states do not allow the exclusion or limitation of incidental or consequential damages. Accordingly, the above limitation may not apply to you.

The warranty extended hereunder is in lieu of any and all other warranties and any implied warranties of merchantability or fitness for a particular purpose is limited in its scope and duration to the terms set forth herein. Some states do not allow limitations on how long an implied warranty lasts. Accordingly, the above limitation may not apply to you.

This warranty gives you specific legal rights. You may also have other rights which vary from state to state.