

## Limited Warranty

ICON Health & Fitness, Inc. (ICON), warrants this product to be free from defects in workmanship and material, under normal use and service conditions, for a period of ninety (90) days from the date of purchase. This warranty extends only to the original purchaser. ICON's obligation under this warranty is limited to replacing or repairing, at ICON's option, the product at one of its authorized service centers. All products for which warranty claim is made must be received by ICON at one of its authorized service centers with all freight and other transportation charges prepaid, accompanied by sufficient proof of purchase. All returns must be pre-authorized by ICON. This warranty does not extend to any product or damage to a product caused by or attributable to freight damage, abuse, misuse, improper or abnormal usage or repairs not provided by an ICON authorized service center, products used for commercial or rental purposes, or products used as store display models. No other warranty beyond that specifically set forth above is authorized by ICON.

ICON is not responsible or liable for indirect, special or consequential damages arising out of or in connection with the use or performance of the product or damages with respect to any economic loss, loss of property, loss of revenues or profits, loss of enjoyment or use, costs of removal, installation or other consequential damages of whatsoever nature. Some states do not allow the exclusion or limitation of incidental or consequential damages. Accordingly, the above limitation may not apply to you. The warranty extended hereunder is in lieu of any and all other warranties and any implied warranties of merchantability or fitness for a particular purpose is limited in its scope and duration to the terms set forth herein. Some states do not allow limitations on how long an implied warranty lasts. Accordingly, the above limitation may not apply to you.

This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

ICON HEALTH & FITNESS, INC., 1500 S. 1000 W., LOGAN, UT 84321-9813

WESLO is a registered trademark of  
ICON Health & Fitness, Inc.

Part No.149092 H02547-C R0898A  
Printed in USA © 1998 ICON Health & Fitness, Inc.

## Limited Warranty

ICON Health & Fitness, Inc. (ICON), warrants this product to be free from defects in workmanship and material, under normal use and service conditions, for a period of ninety (90) days from the date of purchase. This warranty extends only to the original purchaser. ICON's obligation under this warranty is limited to replacing or repairing, at ICON's option, the product at one of its authorized service centers. All products for which warranty claim is made must be received by ICON at one of its authorized service centers with all freight and other transportation charges prepaid, accompanied by sufficient proof of purchase. All returns must be pre-authorized by ICON. This warranty does not extend to any product or damage to a product caused by or attributable to freight damage, abuse, misuse, improper or abnormal usage or repairs not provided by an ICON authorized service center, products used for commercial or rental purposes, or products used as store display models. No other warranty beyond that specifically set forth above is authorized by ICON.

ICON is not responsible or liable for indirect, special or consequential damages arising out of or in connection with the use or performance of the product or damages with respect to any economic loss, loss of property, loss of revenues or profits, loss of enjoyment or use, costs of removal, installation or other consequential damages of whatsoever nature. Some states do not allow the exclusion or limitation of incidental or consequential damages. Accordingly, the above limitation may not apply to you. The warranty extended hereunder is in lieu of any and all other warranties and any implied warranties of merchantability or fitness for a particular purpose is limited in its scope and duration to the terms set forth herein. Some states do not allow limitations on how long an implied warranty lasts. Accordingly, the above limitation may not apply to you.

This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

ICON HEALTH & FITNESS, INC., 1500 S. 1000 W., LOGAN, UT 84321-9813

WESLO is a registered trademark of  
ICON Health & Fitness, Inc.

Part No.149092 H02547-C R0898A  
Printed in USA © 1998 ICON Health & Fitness, Inc.

# SupportPillow

with Magnet & Massage Therapy

Model No. WLRX22080



Thank you for selecting the innovative SUPPORT PILLOW with Magnet & Massage Therapy from WESLO®. The SUPPORT PILLOW combines an ergonomic shape, magnet therapy and gentle massage to help you enjoy more restful sleep each night or while traveling.

To get the most from your WESLO® SUPPORT PILLOW, please read these instructions.

# SupportPillow

with Magnet & Massage Therapy

Model No. WLRX22080



Thank you for selecting the innovative SUPPORT PILLOW with Magnet & Massage Therapy from WESLO®. The SUPPORT PILLOW combines an ergonomic shape, magnet therapy and gentle massage to help you enjoy more restful sleep each night or while traveling.

To get the most from your WESLO® SUPPORT PILLOW, please read these instructions.

**CAUTION:** Do not use magnet therapy if you are pregnant or wearing a pacemaker or any other electrical implants. Magnets are not being sold as medical devices.

**CAUTION:** The pillow case can be removed and washed. Remove the vibration unit before removing the pillow case. Do not wash the pillow or the vibration unit.

#### QUESTIONS?

As a manufacturer, we are committed to providing complete customer satisfaction. If you have questions, we will guarantee complete satisfaction through direct assistance from our factory.

**Please call our CUSTOMER HOT LINE:**

**1-800-999-3756** Mon.–Fri., 6 a.m.–6 p.m. MST

### Installing or Replacing the Batteries

The vibration unit uses two “D” Batteries (not included). To install batteries, unzip the zipper on the top of the pillow case. Gently pull the vibration unit out of the slot in the pillow. Make sure you don’t disconnect the wires between the vibration unit and the on/off switch.

Install two “D” batteries into the battery holder in the position indicated on the diagram inside the holder. Put the vibration unit back into the slot in the pillow and zip the pillow case.

**CAUTION:** Do not use magnet therapy if you are pregnant or wearing a pacemaker or any other electrical implants. Magnets are not being sold as medical devices.

**CAUTION:** The pillow case can be removed and washed. Remove the vibration unit before removing the pillow case. Do not wash the pillow or the vibration unit.

#### QUESTIONS?

As a manufacturer, we are committed to providing complete customer satisfaction. If you have questions, we will guarantee complete satisfaction through direct assistance from our factory.

**Please call our CUSTOMER HOT LINE:**

**1-800-999-3756** Mon.–Fri., 6 a.m.–6 p.m. MST

### Installing or Replacing the Batteries

The vibration unit uses two “D” Batteries (not included). To install batteries, unzip the zipper on the top of the pillow case. Gently pull the vibration unit out of the slot in the pillow. Make sure you don’t disconnect the wires between the vibration unit and the on/off switch.

Install two “D” batteries into the battery holder in the position indicated on the diagram inside the holder. Put the vibration unit back into the slot in the pillow and zip the pillow case.


### Operating the Vibration Unit

The vibration unit is turned on and off by flipping the switch on one side of the pillow.

**CAUTION:** The vibration massage should not be used more than 20 minutes per session. Continuous usage could cause slight bruises.

### Removing the Pillow Case

The pillow case can be removed for cleaning. To do this, unzip the zipper in the pillow case. Pull the vibration unit out of the slot in the pillow. Remove the pillow case from the pillow.



The switch is held in place by two white support plates. The inside plate is secured with two tabs, one on each side of the switch casing.

Press these tabs together with pliers and remove the inside support plate. Pull the switch and the outside support plate through the slot in the pillow case.

To re-install the pillow case, start by inserting the switch and the outside support plate through the slot in the pillow case from the inside. Press the inside support plate over the two tabs on the switch casing. Push the pillow into the pillow case. Insert the vibration unit into the slot in the pillow and zip the pillow case. **Do not wash the vibration unit, the switch or the pillow.**


### Operating the Vibration Unit

The vibration unit is turned on and off by flipping the switch on one side of the pillow.

**CAUTION:** The vibration massage should not be used more than 20 minutes per session. Continuous usage could cause slight bruises.

### Removing the Pillow Case

The pillow case can be removed for cleaning. To do this, unzip the zipper in the pillow case. Pull the vibration unit out of the slot in the pillow. Remove the pillow case from the pillow.



The switch is held in place by two white support plates. The inside plate is secured with two tabs, one on each side of the switch casing.

Press these tabs together with pliers and remove the inside support plate. Pull the switch and the outside support plate through the slot in the pillow case.

To re-install the pillow case, start by inserting the switch and the outside support plate through the slot in the pillow case from the inside. Press the inside support plate over the two tabs on the switch casing. Push the pillow into the pillow case. Insert the vibration unit into the slot in the pillow and zip the pillow case. **Do not wash the vibration unit, the switch or the pillow.**