

Limited Warranty

ICON Health & Fitness, Inc. (ICON), warrants this product to be free from defects in workmanship and material, under normal use and service conditions, for a period of ninety (90) days from the date of purchase. This warranty extends only to the original purchaser. ICON's obligation under this warranty is limited to replacing or repairing, at ICON's option, the product at one of its authorized service centers. All products for which warranty claim is made must be received by ICON at one of its authorized service centers with all freight and other transportation charges prepaid, accompanied by sufficient proof of purchase. All returns must be pre-authorized by ICON. This warranty does not extend to any product or damage to a product caused by or attributable to freight damage, abuse, misuse, improper or abnormal usage or repairs not provided by an ICON authorized service center, products used for commercial or rental purposes, or products used as store display models. No other warranty beyond that specifically set forth above is authorized by ICON.

ICON is not responsible or liable for indirect, special or consequential damages arising out of or in connection with the use or performance of the product or damages with respect to any economic loss, loss of property, loss of revenues or profits, loss of enjoyment or use, costs of removal, installation or other consequential damages of whatsoever nature. Some states do not allow the exclusion or limitation of incidental or consequential damages. Accordingly, the above limitation may not apply to you. The warranty extended hereunder is in lieu of any and all other warranties and any implied warranties of merchantability or fitness for a particular purpose is limited in its scope and duration to the terms set forth herein. Some states do not allow limitations on how long an implied warranty lasts. Accordingly, the above limitation may not apply to you.

This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

ICON HEALTH & FITNESS, INC., 1500 S. 1000 W., LOGAN, UT 84321-9813

WESLO is a registered trademark of
ICON Health & Fitness, Inc.

Part No.155089 J00890-A R0499A

Printed in USA © 1999 ICON Health & Fitness, Inc.

Limited Warranty

ICON Health & Fitness, Inc. (ICON), warrants this product to be free from defects in workmanship and material, under normal use and service conditions, for a period of ninety (90) days from the date of purchase. This warranty extends only to the original purchaser. ICON's obligation under this warranty is limited to replacing or repairing, at ICON's option, the product at one of its authorized service centers. All products for which warranty claim is made must be received by ICON at one of its authorized service centers with all freight and other transportation charges prepaid, accompanied by sufficient proof of purchase. All returns must be pre-authorized by ICON. This warranty does not extend to any product or damage to a product caused by or attributable to freight damage, abuse, misuse, improper or abnormal usage or repairs not provided by an ICON authorized service center, products used for commercial or rental purposes, or products used as store display models. No other warranty beyond that specifically set forth above is authorized by ICON.

ICON is not responsible or liable for indirect, special or consequential damages arising out of or in connection with the use or performance of the product or damages with respect to any economic loss, loss of property, loss of revenues or profits, loss of enjoyment or use, costs of removal, installation or other consequential damages of whatsoever nature. Some states do not allow the exclusion or limitation of incidental or consequential damages. Accordingly, the above limitation may not apply to you. The warranty extended hereunder is in lieu of any and all other warranties and any implied warranties of merchantability or fitness for a particular purpose is limited in its scope and duration to the terms set forth herein. Some states do not allow limitations on how long an implied warranty lasts. Accordingly, the above limitation may not apply to you.

This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

ICON HEALTH & FITNESS, INC., 1500 S. 1000 W., LOGAN, UT 84321-9813

WESLO is a registered trademark of
ICON Health & Fitness, Inc.

Part No.155089 J00890-A R0499A

Printed in USA © 1999 ICON Health & Fitness, Inc.

WESLO®

Thera-Foam SoundAsleep™ Pillow
with Magnet & Sound Therapy

Model No. WLRX24590



Thank you for selecting the innovative Thera-Foam SoundAsleep™ Pillow from WESLO®. The Thera-Foam SoundAsleep Pillow combines an ergonomic shape, special viscoelastic foam, magnet therapy, and six soothing sounds to help you enjoy more restful sleep each night.

To get the most from your Thera-Foam SoundAsleep™ Pillow, please read these instructions.

WESLO®

Thera-Foam SoundAsleep™ Pillow
with Magnet & Sound Therapy

Model No. WLRX24590



Thank you for selecting the innovative Thera-Foam SoundAsleep™ Pillow from WESLO®. The Thera-Foam SoundAsleep Pillow combines an ergonomic shape, special viscoelastic foam, magnet therapy, and six soothing sounds to help you enjoy more restful sleep each night.

To get the most from your Thera-Foam SoundAsleep™ Pillow, please read these instructions.

CAUTION: Do not use magnet therapy if you are pregnant or if you are wearing a pacemaker or any other electrical implants. Magnets are not being sold as medical devices.

CAUTION: The pillow case can be removed and washed. Remove the sound system before removing the pillow case. Do not wash the pillow or the sound system.


QUESTIONS?

As a manufacturer, we are committed to providing complete customer satisfaction. If you have questions, we will guarantee complete satisfaction through direct assistance from our factory.

Please call our CUSTOMER HOT LINE:
1-800-999-3756 Mon.–Fri., 6 a.m.–6 p.m. MST

Installing or Replacing the Batteries

The Sound System uses two AA batteries (not included). To install batteries, press one finger against the battery compartment door and push down gently until the door feels loose. Then, swing the door open and insert the batteries. Make sure the batteries are oriented as shown on the inside of the battery door. To close the door, fold it down and gently press it upwards until it snaps into place.



CAUTION: Do not use magnet therapy if you are pregnant or if you are wearing a pacemaker or any other electrical implants. Magnets are not being sold as medical devices.

CAUTION: The pillow case can be removed and washed. Remove the sound system before removing the pillow case. Do not wash the pillow or the sound system.


QUESTIONS?

As a manufacturer, we are committed to providing complete customer satisfaction. If you have questions, we will guarantee complete satisfaction through direct assistance from our factory.


Please call our CUSTOMER HOT LINE:
1-800-999-3756 Mon.–Fri., 6 a.m.–6 p.m. MST

Installing or Replacing the Batteries

The Sound System uses two AA batteries (not included). To install batteries, press one finger against the battery compartment door and push down gently until the door feels loose. Then, swing the door open and insert the batteries. Make sure the batteries are oriented as shown on the inside of the battery door. To close the door, fold it down and gently press it upwards until it snaps into place.



Operating the Sound System



The built-in sound system offers six relaxing sounds to choose from: ocean waves, heartbeat, night crickets, summer rain, mountain stream, or white noise. Volume adjustment and automatic shut-off ensure sound sleep. Fall asleep to gentle sounds while your neck is cradled in therapeutic support.

Selecting Sounds

To change the sound, push the Mode Button. This button scrolls through the available sounds one at a time in a sequence. Keep pushing the button until the desired sound is heard.


Volume Control

To raise or lower the volume, turn the Volume Button until you have the desired volume.

Turning the Sound System On or Off.

To turn the Sound System on or off, push the On/Off Button. The sound system shuts off automatically after 20 minutes of operation.

Operating the Sound System



The built-in sound system offers six relaxing sounds to choose from: ocean waves, heartbeat, night crickets, summer rain, mountain stream, or white noise. Volume adjustment and automatic shut-off ensure sound sleep. Fall asleep to gentle sounds while your neck is cradled in therapeutic support.

Selecting Sounds

To change the sound, push the Mode Button. This button scrolls through the available sounds one at a time in a sequence. Keep pushing the button until the desired sound is heard.

Volume Control

To raise or lower the volume, turn the Volume Button until you have the desired volume.

Turning the Sound System On or Off.

To turn the Sound System on or off, push the On/Off Button. The sound system shuts off automatically after 20 minutes of operation.