

NOTE: You must determine what type of Safety Bar is being replaced. See Serial Number Break Guide in Service Bulletins and check order history to determine correct Safety Bar parts list to use.

160-019 SAFETY BAR
VARSITY (D SERIES)
RIGHT ORIENTATION

160-018 SAFETY BAR
VARSITY (D SERIES)
LEFT ORIENTATION

160-009 SAFETY BAR
A & MR SERIES
RIGHT ORIENTATION

160-008 SAFETY BAR
A & MR SERIES
LEFT ORIENTATION
(SHOWN EXPLODED)

IMAGE WILL VARY SLIGHTLY FOR
VAROIUS SAFETY BAR ASSEMBLIES AND
OPPOSITE MOUNTING ORIENTATION
(SEE BOM FOR PART NUMBER)

DETAIL B
SCALE 1 : 2

8 NOT USED ON
VARSITY (D-SERIES)
SEE BOM

6X

4X

NOTE: ASSEMBLY MAY VARY
FOR OPPOSITE MOUNTING ORIENTATION
(SEE BOM FOR PART NUMBERS)

MATRIX

DWG NO.			
160-008, 009, 018 & 019 SERVICE			
DESCRIPTION:			
(Power Racks)			
DRAWN BY:	LMB	DATE:	2013.MAR.21
UPDATED BY:	L.M.B	DATE:	2017.MAR.07