


**Free Weight 5570 and 5571
Squat Rack With Adjustable Stop**

Instructions:

Hover over the balloons to view the part information.
Click the balloon to add the part to your shopping cart.

Additional Parts Not Shown:

55299 Owners Manual, Free Weight
55571 Squat Rack Instruction



5570 and 5571 - Squat Rack With Adjustable Stop

ITEM	QTY	PART NO.	DESCRIPTION
1	1	5570-201	Left Hand Side Assembly
2	1	5570-200	Right Hand Side Assembly
3			Removed
4	1	5570-202	Lower Brace
5	1	5570-203	Upper Brace
6	2	5572-200	Bar Stop
7	8	JC782834	SHCS .50-13 x 3.00
8	4	JC782840	SHCS .50-13 x 4.00
9	12	HN784900	Locknut .50-13
10	2	5420-029	Adjustable Bar Assembly
11	8	01066	Plastic Fastener
12	2	5570-205	Barbell Holder
13	2	5570-310	Bumper
14	2	JC780417	BHSCS .50-13 x 1.00
15	2	JS388300	Lockwasher .50-13
16			Removed
17	4	5570-206	Detent Pin
18	2	5570-309	Bumper

ITEM	QTY	PART NO.	DESCRIPTION
19	2	PP080202	Hole Plug 1.19 Dia. x 11 G
20	2	PP090201	Insert
21	2	PP090206	Insert
22	2	5572-304	Bumper
23			Removed
24	2	PN660200	Hole Plug
25	10	5330M040	Hole Plug
26	2	PN660201	Hole Plug
27	2	5340P003	Weight Tube 6"
28	4	5490P010	Weight Tube 8"
29	4	5490P009	Weight Tube 10"
30	1	3900-388	Cybex Decal 1.00 Horiz. Blk/Plm
30			Removed 7-03
30	1	3900-414	Cybex Decal 1.00 Horiz. Wht/Wht
31	1	5220-365	Warning Decal
32	10	5220-367	Spacer
33	1	55571	Squat Rack Instr. (not shown)