

93C Lifecycle

93C-0100-01

Parts Manual


1/5/2019 7:22:41 AM



Table of Contents



<u>Alternator with Pulley</u>	3
<u>Belts</u>	4
<u>Cables</u>	5
<u>Console Assembly</u>	6
<u>Console Support Assembly</u>	7
<u>Crankshaft and Bearing Assembly</u>	8
<u>Front Wheel Assembly</u>	9
<u>General Assembly</u>	10
<u>Handlebar Assembly</u>	11
<u>Idler Bracket Assembly</u>	12
<u>Intermediate Shaft and Bearing Assembly</u>	13
<u>Left Side Shroud and Crank Arm</u>	14
<u>PCB Mounting Bracket Assembly</u>	15
<u>Resistor Assembly</u>	16
<u>Right Side Shroud and Crank Arm</u>	17
<u>Seat Latch Assembly</u>	18
<u>Seat Post Assembly</u>	19
<u>Seat Post Shrouds</u>	20

Alternator with Pulley




Ref #	Part Number	Qty	Description
-	OK61-01027-0000	1	Flywheel: 6.75" D
-	0017-00103-0117	1	Hardware: Locking Nut 1/2" ID
-	0017-00101-0956	1	Hardware: Bolt 2"
-	0017-00104-0044	2	Hardware: Washer 0.75" OD
-	0017-00009-0841	1	Alternator
-	0017-00009-0895	1	Alternator Brush Kit

Belts




Ref #	Part Number	Qty	Description
-	OK63-01405-0000	1	BELT: POLY-V; 390J6; 39.00 IN
-	GK63-00002-0079	1	Kit: Upright/Rec Belt And Pulley

Cables




Ref #	Part Number	Qty	Description
-	AK63-00037-0002	1	Console Cable
-	AK63-00029-0001	1	Power Control Cable Assembly
-	AK63-00050-0000	1	Reed Switch Bracket Assembly
-	AK36-00021-0003	1	Cable Assembly

Console Assembly




Ref #	Part Number	Qty	Description
-	A084-92220-A005	1	Console Board - Upper
-	AK63-00166-0001	1	Bezel with Overlay Assembly. English Metric
-	AK63-00121-0000	1	Console Case Assembly
-	0017-00101-1650	13	Hardware: Phillips Pan Screw 0.375"
-	AK63-00161-0001	1	Console Assembly English Metric
-	OK63-01029-0001	1	Battery Door
-	OK63-01028-0000	1	Case
-	OK63-01277-0000	1	Console Decal

Console Support Assembly




Ref #	Part Number	Qty	Description
-	0K63-01113-0000	1	Polar Bracket
-	0K63-01178-0002	1	Console Support Elbow 6"
-	0K63-01192-0004	1	Handlebar Cover Left
-	AK63-00066-0001	1	Life Cycle 93Ci Console Support Assembly
-	AK63-00089-0002	1	Console Support Weldment Assembly
-	0017-00042-1132	1	End Cap
-	0017-00101-1755	4	Hardware: TORX Bolt 0.75"
-	0017-00103-0318	2	Hardware: Nut
-	0K63-01192-0003	1	Handlebar Cover Right
-	0017-00101-1721	4	Hardware: Pan Screw

Crankshaft and Bearing Assembly




Ref #	Part Number	Qty	Description
-	OK63-01018-0000	1	Crank Pulley
-	GK63-00002-0077	1	Crankshaft and Bearing Kit
-	OK63-01129-0000	2	Hardware: Small Thrust Washer
-	AK63-00051-0000	1	Pulley Assembly
-	OK63-01129-0001	2	Hardware: Large Thrust Washer
-	0017-00100-0243	2	Hardware: Bowed Retaining Ring .984"
-	0017-00101-1705	2	Hardware: Bolt 0.5"
-	0017-00101-1715	3	Hardware: TORX Cap Screw 0.625"
-	OK63-01095-0001	3	Crank Arm Hub
-	OK63-01012-0001	1	Crankshaft
-	0017-00100-0241	2	Hardware: Small Snap Ring .984"
-	0017-00104-0409	2	Hardware: Washer 1.125" OD
-	OK63-01344-0000	2	Hardware: Needle Bearing
-	0017-00104-0458	3	Hardware: Flat Washer 0.75" OD

Front Wheel Assembly




Ref #	Part Number	Qty	Description
-	OK63-01041-0000	2	Hardware: Flat Washer
-	AK63-00016-0001	2	Wheel/Bearing Assembly
-	OK63-01039-0000	2	Wheel Insert
-	0017-00101-1747	4	Hardware: Pan Screw 0.75"
-	0017-00101-1611	2	Hardware: Insert Screw
-	AK63-00017-0001	2	Front Wheel Assembly

General Assembly




Ref #	Part Number	Qty	Description
-	0017-00101-1253	8	Hardware: Screw
-	OK63-01030-0001	1	Accessory Tray
-	GK63-00002-0003	1	C-SAFE Network Kit
-	SK40-00045-0001	1	Polar HR Kit
-	GK63-00002-0044	1	Hardware Bag
-	GK63-00002-0044	1	Hardware Bag
-	GK63-00002-0044	1	Hardware Bag
-	GK63-00002-0044	1	Hardware Bag
-	GK63-00002-0044	1	Hardware Bag
-	GK63-00002-0044	1	Hardware Bag
-	GK63-00002-0044	1	Hardware Bag
-	GK63-00002-0044	1	Hardware Bag
-	GK63-00002-0044	1	Hardware Bag
-	GK63-00002-0044	1	Hardware Bag
-	OK63-01145-0002	2	Upper Cover
-	0017-00101-1744	4	Hardware: Phillips Pan Screw
-	0017-00101-1755	8	Hardware: TORX Bolt 0.75"

Handlebar Assembly




Ref #	Part Number	Qty	Description
-	AK63-00091-0001	1	Handle Bar
-	AK63-00084-0000	1	Handlebar
-	OK63-01177-0002	1	Dipped Grip

Idler Bracket Assembly




Ref #	Part Number	Qty	Description
-	AK63-00008-0000	1	Idler w/Bearing
-	OK63-01050-0000	1	Idler Bracket
-	AK63-00021-0000	1	Idler Bracket Assembly
-	0017-00103-0218	1	Hardware: Lock Nut 3/8" ID

Intermediate Shaft and Bearing Assembly




Ref #	Part Number	Qty	Description
-	GK63-00002-0007	1	Intermediate Shaft and Bearing Assembly
-	0017-00100-0242	1	Hardware: Retaining Ring .781"
-	118E-00001-0124	1	Auto-Start Magnet
-	0017-00104-0455	2	Hardware: Delrin Washer 1.250" OD
-	GK63-00002-0079	1	Kit: Upright/Rec Belt And Pulley

Left Side Shroud and Crank Arm




Ref #	Part Number	Qty	Description
-	OK39-01042-0006	1	Crank Arm Left
-	0017-00101-1742	3	Hardware: TORX Screw 0.75"
-	OK63-01238-0004	1	Left Pedal Strap
-	0017-00101-1702	3	Hardware: Screw
-	AK63-00263-0004	1	Pedal: Left
-	0017-00104-0262	2	Hardware: Washer
-	AK63-00177-0002	1	Left Side Shroud
-	OK63-01084-0001	1	Shroud Plug
-	OK63-01314-0000	1	Decal

PCB Mounting Bracket Assembly




Ref #	Part Number	Qty	Description
-	0017-00101-0975	2	Hardware: Mounting Bolt 0.375"
-	0017-00003-0685	1	6V Battery
-	0017-00042-0821	4	Hardware: Plastic Grommet
-	0017-00009-0915	1	Cable-Insulated Clamp
-	OK63-01211-0000	1	Battery Mounting Bracket
-	0017-00101-0823	4	Hardware: Screw 0.75"
-	B084-92218-0000	1	PCB Circuit Board

Resistor Assembly




Ref #	Part Number	Qty	Description
-	0017-00103-0081	3	Hardware: Hex Nut ID
-	OK63-01165-0000	2	Resistor Bracket
-	AK63-00049-0000	1	PCB Mounting Bracket
-	OK63-01215-0000	1	Hardware: Resistor Retainer
-	AK63-00047-0001	1	Resistor Assembly
-	AK63-00093-0000	1	Alternator w/Pulley
-	0017-00101-1282	2	Hardware: TORX Screw 0.375"
-	0017-00104-0458	1	Hardware: Flat Washer 0.75" OD
-	AK36-00021-0003	1	Cable Assembly
-	OK63-01166-0000	1	Resistor Mounting Rod
-	0017-00103-0177	1	Hardware: Nut
-	OK63-01030-0001	1	Accessory Tray
-	OK63-01146-0001	1	Lower Cover
-	100E-00002-0084	1	Resistor

Right Side Shroud and Crank Arm




Ref #	Part Number	Qty	Description
-	OK39-01042-0005	1	Crank Arm Right
-	AK63-00177-0001	1	Right Side Shroud
-	OK63-01314-0000	1	Decal
-	0017-00101-1742	8	Hardware: TORX Screw 0.75"
-	OK63-01238-0003	1	Right Pedal Strap
-	0017-00101-1702	3	Hardware: Screw
-	AK63-00263-0003	1	Pedal: Right

Seat Latch Assembly




Ref #	Part Number	Qty	Description
-	OK63-01064-0000	1	Latch Bracket
-	OK63-01117-0000	1	Latch Spring
-	AK63-00113-0001	1	Link Shaft Assembly
-	0017-00101-0333	2	Hardware: Screw 0.3125"
-	0017-00042-1129	2	Hardware: Nyliner Ring - 1/2" Diameter
-	0017-00100-0050	1	Hardware: E-Ring .5"
-	OK63-01061-0000	1	Latch Rack
-	AK63-00043-0001	1	Seat Latch Assembly

Seat Post Assembly



Ref #	Part Number	Qty	Description
-	0017-00042-1131	1	Bumper
-	AK63-00099-0001	1	Seat Post Assembly
-	OK63-01045-0000	1	Guide Base
-	OK63-01310-0000	1	Seat Post Decal
-	0017-00104-0064	4	Hardware: Lock Washer 0.586" OD
-	OK63-01210-0000	1	Spring Support Bracket
-	OK63-01049-0001	1	Seat Adjustment Rack
-	AK63-00045-0002	1	Seat Post Assembly
-	OK63-01044-0000	1	Extrusion Guide Cap
-	0017-00101-1121	4	Hardware: Bolt 4.6875"
-	0017-00101-1750	1	Hardware: Screw 0.75"
-	0017-00101-1614	3	Hardware: Screw 0.625"
-	AK63-00229-0003	1	Deluxe Seat

Seat Post Shrouds



Ref #	Part Number	Qty	Description
-	0017-00101-1741	1	Hardware: Screw
-	OK63-01092-0010	1	Left Seat Post Shroud
-	OK63-01092-0009	1	Right Seat Post Shroud

