

LC-8500 Exercise Bike

LC85-0100-34


Parts Manual

1/5/2019 14:42:40 PM

Table of Contents


<u>Component Assembly 1</u>	3
<u>Component Assembly 2</u>	4

Component Assembly 1



Ref #	Part Number	Qty	Description
-	0017-00009-0795	2	Leg Leveler
-	AK18-00079-0015	1	Shroud Assembly with Decal - Left
-	AK18-00127-0005	1	Seat with Seat Post Assembly
-	AK17-00221-0001	1	Overlay Bezel English/Metric
-	AK17-00217-0000	1	Handlebar with Electrode
-	OK18-01243-0001	1	Console Case
-	SK18-00016-0000	2	Wheel Bearing Assembly
-	AK17-00189-0002	1	Pedal with Strap - Left
-	0017-00003-0757	1	9 Volt Battery
-	SK18-00156-0004	1	Kit: Serv; Seatpost-Weld BM
-	SK18-00136-0000	1	Seat Plunger Assembly
-	AK18-00070-0001	1	Stabilizer Bar
-	AK17-00189-0001	1	Pedal with Strap - Right
-	OK18-01156-0001	1	Front Cap
-	OK17-01033-0000	2	Foot
-	OK18-01265-0004	1	Seat
-	AK18-00078-0015	1	Shroud Assembly with Decal - Right
-	AK17-00220-0001	1	Console English/Metric
-	AK46-00020-0005	1	Seatpost Shroud

Component Assembly 2



Ref #	Part Number	Qty	Description
-	OK51-01009-0000	1	Crank Arm Pulley
-	OK18-01104-0001	2	Clamp
-	AK49-00017-0000	1	Lower Console Cable
-	SK51-00024-0000	1	Crank Arm with Pulley
-	AK18-00029-0001	1	Hardware: Bearing Nut - Left
-	OK18-01281-0000	1	Crankarm
-	AK49-00012-0000	1	Upper Console Cable
-	OK18-01059-0002	1	Hardware: Locknut
-	AK46-00016-0000	1	Freewheel Pulley Assembly
-	AK46-00024-0002	1	Idler Arm Assembly
-	GK18-00004-0023	1	Crankarm Bearing Kit
-	AK49-00013-0000	1	Alternator Control Assembly
-	0017-00009-0841	1	Alternator
-	SK17-00106-0000	1	Alternator Pulley Assembly
-	AK46-00052-0000	1	Cog Pulley
-	AK18-00116-0001	1	Hardware: Bearing Nut - Right
-	OK46-01008-0005	1	Idler Pulley
-	AK46-00010-0000	1	Main Cable Assembly
-	OK46-01042-0001	1	Pulley Shaft
-	OK46-01009-0000	1	Power Grip Belt
-	OK18-01280-0000	1	Hardware: Tabbed Lock Washer
-	OK18-01104-0002	2	Clamp

Ref #	Part Number	Qty	Description
-	0017-00009-1324	1	Belt: Poly-V; 49.00 IN

