

Strength Smith Machine

PL05

Parts Manual


1/5/2019 15:48:35 PM



Table of Contents

Component Assembly	3
--	---

Component Assembly



Ref #	Part Number	Qty	Description
-	PL06-M0013-0000	1	Linear Shafting
-	OK50-P051A-0000	1	NLA: COVER;OK50;MACH COVER;STRENGTH
-	8039501	1	Label Warning Triangle 10-0099-067 BNR
-	SK50-S0020-0000	1	Kit; Serv; Bar; Smith
-	OK50-P051C-0000	1	NLA: COVER;OK50;MACH COVER;STRENGTH
-	0017-00042-0969	32	Finishing Cap - Large (RH20)
-	AK50-CL092-0001	1	Cable; 92 Ball One End; Strength
-	0017-00042-0999	1	Connector: Grease Fittings
-	3237801	4	Pulley 4.5" OD
-	SK50-S0031-0000	4	Bearing with Grease; Strength
-	OK50-P051B-0000	1	NLA: COVER;OK50;MACH COVER;STRENGTH
-	OK50-P051D-0000	1	NLA: COVER;OK50;MACH COVER;STRENGTH
-	0017-00042-0991	2	NLA: RUBBER DONUT; 1"; STRENGTH

