




ARCTIC SILVER 95Ci Upright Bike



Customer Support Services  
**PARTS MANUAL** rev 29 Jan 2010

**ARCTIC SILVER 95Ci****95C-0XXX-02****REFERENCES****S/N CCP100000 and UP**


---

|                                                                         |                                                       |
|-------------------------------------------------------------------------|-------------------------------------------------------|
| OPERATION MANUAL                                                        | M051-00K63-A064                                       |
| HARDWARE BAG                                                            | GK63-00002-0044                                       |
| NETWORK C-SAFE KIT                                                      | GK63-00002-0003                                       |
| POWER OPTION KIT – 120V                                                 | GK63-00002-0005                                       |
| POWER OPTION KIT – 220/50 UK                                            | GK63-00002-0039                                       |
| POWER OPTION KIT – 240V+ AUS                                            | GK63-00002-0040                                       |
| POWER OPTION KIT – 220/50                                               | GK63-00002-0041                                       |
| TOUCH UP PAINT:<br>SPRAY CAN<br>.5 OZ BOTTLE W/APPLICATOR<br>.33 OZ PEN | 0017-00008-0204<br>0017-00008-0205<br>0017-00008-0206 |
| SERVICE MANUAL                                                          | M051-00K63-A009                                       |

|                                               | Page |
|-----------------------------------------------|------|
| CONSOLE COMPONENTS .....                      | 4    |
| CONSOLE MOUNTING SCREWS AND POLAR COVERS..... | 5    |
| ALTERNATOR W/PULLEY .....                     | 6    |
| CRANKSHAFT AND BEARING ASSEMBLY.....          | 7    |
| INTERMEDIATE SHAFT AND BEARING ASSEMBLY.....  | 8    |
| SEAT LATCH ASSEMBLY .....                     | 9    |
| SEAT POST ASSEMBLY .....                      | 10   |
| SEAT POST SHROUDS.....                        | 11   |
| IDLER BRACKET ASSEMBLY.....                   | 12   |
| CONSOLE SUPPORT ASSEMBLY.....                 | 13   |
| LEFT SIDE SHROUD AND CRANKARM .....           | 14   |
| RIGHT SIDE SHROUD AND CRANKARM.....           | 15   |
| PCB MOUNTING BRACKET ASSEMBLY.....            | 16   |
| FRONT WHEELS.....                             | 17   |
| RESISTOR ASSEMBLY.....                        | 18   |
| HANDLEBAR ASSEMBLY.....                       | 19   |
| BELTS.....                                    | 20   |
| CABLES.....                                   | 21   |

**ARCTIC SILVER 95Ci**  
**Console Components**


**95C-0XXX-02**  
**S/N CCP100000 and UP**





| Console Assembly        | Bezel/Switch W/Overlay Assy. |
|-------------------------|------------------------------|
| AK63-00160-0001 Eng Met | AK63-00165-0001 Eng Met      |
| AK63-00160-0003 Ger Met | AK63-00165-0003 Ger Met      |
| AK63-00160-0004 Spn Met | AK63-00165-0004 Spn Met      |
| AK63-00160-0006 Jap Met | AK63-00165-0006 Jap Met      |
| AK63-00160-0007 Frn Met | AK63-00165-0007 Frn Met      |
| AK63-00160-0008 Itl Met | AK63-00165-0008 Itl Met      |
| AK63-00160-0009 Dut Met | AK63-00165-0009 Dut Met      |
| AK63-00160-0010 Por Met | AK63-00165-0010 Por Met      |

**ARCTIC SILVER 95Ci**  
**Console Screws & Polar Covers**

**95C-0XXX-02**  
**S/N CCP100000 and UP**








## ARCTIC SILVER 95Ci


95C-0XXX-02


### Intermediate Shaft and Bearing Assembly

S/N CCP100000 and UP









## ARCTIC SILVER 95Ci



### Seat Post Shrouds

95C-0XXX-02


S/N CCP100000 and UP

Left Seat Post Shroud  
OK63-01092-0010

Screw  
0017-00101-1741




Right Seat Post Shroud  
OK63-01092-0009



**ARCTIC SILVER 95Ci**  
**Console Support Assembly**

**95C-0XXX-02**  
**S/N CCP100000 and UP**




## ARCTIC SILVER 95Ci

### Left Side Shroud and Crankarm

95C-0XXX-02

S/N CCP100000 and UP




## ARCTIC SILVER 95Ci

### Right Side Shroud and Crankarm

95C-0XXX-02


S/N CCP100000 and UP




**ARCTIC SILVER 95Ci**  
**PCB Mounting Bracket Assembly**


**95C-0XXX-02**  
**S/N CCP100000 and UP**


Assembly Number – AK63-00049-0000
















# ARCTIC SILVER 95Ci

## Cables

95C-0XXX-02  
S/N CCP100000 and UP

### CABLE ASSEMBLY POWER CONTROL TO ALTERNATOR AK63-00029-0001




### CONSOLE TO ACB CABLE AK63-00037-0002

### LOWER CONSOLE CABLE AK63-00038-0000

### CABLE ASSEMBLY AK63-00028-0001

### LIFE PULSE EXTENSION AK63-00069-0000



### POLAR CABLE AK36-00021-0003 POLAR CABLE W/BACKET AK63-00120-0000