


LifeCycle 95CXXL General Assembly


95CXXL-0000, -0100, -0601-01




Operation Manual	M051-00K63-A064
Service Manual	M051-00K63-A009
Optional Power Plug-In Unit (Not a battery charger)	
Kit SERV Power 120/60	GK63-00002-0005
Kit SERV Power 220/50UK	GK63-00002-0039
Kit SERV Power 240UK	GK63-00002-0040
Kit SERV Power 220/50CON	GK63-00002-0041

**LifeCycle 95CXXL
Console Overlay Bezel Assembly**

95CXXL-0000, -0100, -0601-01




Console Assembly	Overlay Bezel
AK63-00141-0001 Eng Met	AK63-00142-0001 Eng Met
AK63-00141-0009 Dut Met	AK63-00142-0009 Dut Met




Alternator Pulley
OK61-02500-0001


Alternator
0017-00009-0841






Crank Shaft and Crank Bearing Assembly




Intermediate Shaft and Bearing Assembly – GK63-00002-0007











Console Support Assembly - AK63-00139-0000



Note: GK63-00139-0000 Kit includes all parts above.


Items with an asterisk (*) symbol next to the name, cannot be purchased separately.

Left Side Shroud and Crankarm



LifeCycle 95CXXL
Right Side Shroud and Crankarm


95CXXL-0000, -0100, -0601-01




LifeCycle 95CXXL

95CXXL-0000, -0100, -0601-01

P.C.B. Mounting Bracket Assembly – AK63-00049-0000






Note: AK63-00017-0000 Assembly includes all parts above.

Items with an asterisk (*) symbol next to the name, cannot be purchased separately.

**LifeCycle 95CXXL
Resistor Assembly**

95CXXL-0000, -0100, -0601-01




Items with an Asterisk () symbol next to the part name, are “Hot-Linked” to the block diagram on the last page.

LifeCycle 95CXXL


95CXXL-0000, -0100, -0601-01

Handlebar Assembly - AK63-00091-0000




Note: AK63-00091-0000 Assembly includes all parts above.

Items with an Asterisk () symbol next to the part name, are "Hot-Linked" to the block diagram on the last page.



Alternator Belt
OK63-01065-0000



Intermediate Belt
OK63-01066-0001

