




END OF LIFE




| | |
|--|-----------------|
| Operation Manual | M051-00K20-A347 |
| Service Manual | M051-00K39-A012 |
| Polar Transmitter XS | AK40-00045-0003 |
| Polar Transmitter MED | AK40-00045-0002 |
| Polar Transmitter XL | AK40-00045-0004 |
| Optional Power Plug-In Unit (Not a batter charger) | |
| Kit SERV Power 120/30 | GK63-00002-0005 |
| Kit SERV Power 220/50UK | GK63-00002-0039 |
| Kit SERV Power 240UK | GK63-00002-0040 |
| Kit SERV Power 220/50CON | GK63-00002-0041 |




| Console Assembly | Overlay Bezel | Upper Overlay | Lower Overlay |
|-------------------------|-------------------------|-------------------------|-------------------------|
| AK63-00141-0001 Eng Met | AK63-00142-0001 Eng Met | 0K63-01255-0001 Eng Met | 0K63-01098-0001 Eng Met |
| AK63-00141-0009 Eng Met | AK63-00142-0009 Eng Met | 0K63-01255-0009 Eng Met | 0K63-01098-0009 Eng Met |






**Crank Shaft and Crank Bearing
Assembly - GK63-00002-0006**


CBK100000 and up









Note: GK63-00002-0007 Kit includes all parts shown.


Items with asterisks (*) cannot be purchased separately.















Note: AK63-00139-0000 Kit includes all parts above.

Items with asterisks (*) cannot be purchased separately.












Note: AK63-00017-0000 Assembly includes all parts shown.

Items with asterisks (*) cannot be purchased separately.






Note: AK63-00091-0000 Assembly includes all parts shown.



Alternator Belt
OK63-01065-0000



Intermediate Belt
OK63-01066-0001

