




ARCTIC SILVER QUIET DRIVE CROSS
TRAINER 93X-0XXX-04



Customer Support Services
PARTS MANUAL rev 14 Jun 2010

ARCTIC SILVER QUIET DRIVE 93X
REFERENCES


93X-0XXX-04
S/N XWF100000


OPERATION MANUAL – (ENG)	M051-00K62-A181
OPERATION MANUAL – (F/S/P)	M051-00K62-A182
OPERATION MANUAL – (G/D/I)	M051-00K62-A183
OPERATION MANUAL – (JAP)	M051-00K62-A184
SERVICE MANUAL	M051-00K62-A149
TOUCH UP PAINT: SPRAY CAN .5 OZ BOTTLE W/APPLICATOR .33 OZ PEN	0017-00008-0204 0017-00008-0205 0017-00008-0206
HARDWARE BAG	AK62-00152-0001
POWER CABLE WITH BRACKET ASSEMBLY CONSISTS OF: 120" COAX CABLE ASSY. 120" POWER EXTENSION CABLE ACCESS PANEL BRACKET F-TYPE PANEL CONNECTOR #8 PLASTIC GROMMET	AK62-00210-0000 AK32-00020-0002 AK32-00078-0001 0K62-01179-0001 0017-00021-2846 0017-00042-0754
PLUG IN OPTION 120/60	GK62-00002-0018
PLUG IN OPTION 240/50 UK	GK62-00002-0019
PLUG IN OPTION 240v AUS	GK62-00002-0020
PLUG IN OPTION 230/50 CONT.	GK62-00002-0021
C-SAFE KIT	GK63-00002-0003


	Page
CONSOLE SUPPORT & DEADSHAFT COVERS	4
HANDLEBARS AND BULLHORNS	5
CONSOLE AND RELATED COMPONENTS.....	6
UPPER FRAME HARDWARE	7
ROCKER ARMS AND PEDAL LEVERS	8
CRANK COVER AND LOWER CAPS	9
LOWER FRAME SHROUDS AND HARDWARE	10
PEDAL LEVER COMPONENTS	11
PCB, BATTERY, REED SWITCH & BRACKET	12
BEARING-INSERT ASSEMBLY	13
CRANK ARM PULLEY ASSEMBLY.....	14
DRIVE MODULE	15
DRIVE MODULE HARDWARE	16
CABLES.....	17

Note: Adding the version –02 attachable LCD TV to this model makes it a 93XER-XXX-04. See the Entertainment parts list marked LCD-0XXX-02 for the part numbers and descriptions for the attachable LCD TV, remote and hardware for this product.

Note: The 93X has both Contact Heart Rate and Telemetry and is pre-wired for attachable TV's.








CONSOLE	OVERLAY/BEZEL/SWITCH	LANGUAGE
AK62-00365-0001	AK62-00190-0001	Eng/Eng
AK62-00365-0002	AK62-00190-0001	Eng+Met
AK62-00365-0003	AK62-00190-0003	Ger/Met
AK62-00365-0004	AK62-00190-0004	Spn/Met
AK62-00365-0006	AK62-00190-0006	Jap/Met
AK62-00365-0007	AK62-00190-0007	Frn/Met
AK62-00365-0008	AK62-00190-0008	Ital/Met
AK62-00365-0009	AK62-00190-0009	Dut/Met
AK62-00365-0010	AK62-00190-0010	Port/Met
AK62-00365-0014	AK62-00190-0001	Turk/Met

Items Not Shown	
Accessory Tray	0K62-01022-0000
Accessory Tray Mounting Screws (2)	0017-00101-1846



ARCTIC SILVER QUIET DRIVE 93X

Rocker Arms & Pedal Levers


93X-0XXX-04

S/N XWF100000

Rocker Arms Kit
GK62-00002-0070
contents:

Rocker Arms (2)
Hardened Spacers (2)
Oilite Washers (2)
Retaining Rings (2)
Loctite 620
Alcohol pad

Rocker Arms
AK62-00062-0001
Shaft Collar w/Screws
0K61-01259-0000




ARCTIC SILVER QUIET DRIVE 93X

Crank Cover and Lower Caps

93X-0XXX-04

S/N XWF100000



Crank Cover
OK61-03100-0002
2 - Mounting screws
0017-00101-1837

Stabilizer Caps
4 - OK62-01003-0000


Front frame Cap
OK62-01004-0000
Mounting Screws
(Located on front sides of Ladder Frame Cover)
2- 0017-00101-1795

ARCTIC SILVER QUIET DRIVE 93X

Lower Frame Shrouds & Hardware

93X-0XXX-04

S/N XWF100000





ARCTIC SILVER QUIET DRIVE 93X

Pedal Lever Assembly Components

93X-0XXX-04

S/N XWF100000





ARCTIC SILVER QUIET DRIVE 93X
Bearing-Insert Assembly – AK62-00299-0000

93X-0XXX-04
S/N XWF100000

This assembly is used 4 times on the drive module assembly.


Service Kit-
GK62-00002-0044
Includes:

- 1 - crankshaft
- 2 - bearings
- 2 - sets of bearing flanges
- 4 - weldnuts and flat washers
- 4 - bolts


Service Kit- GK62-00002-0045
Includes:


- 1 - intermediate shaft
- 2 - bearings
- 2 - sets of bearing flanges
- 4 - weldnuts and flat washers
- 4 - bolts


Bearing Flanges (2)
OK62-01220-0000



1" Bearing
OK62-01221-0000







ARCTIC SILVER QUIET DRIVE 93X

Cables

93X-0XXX-04
S/N XWF100000

