

## Parts List & Parts Diagram

PART No.	DESCRIPTION	Q'TY	PART No.	DESCRIPTION	Q'TY	PART No.	DESCRIPTION	Q'TY
001	ALUMINUM BEAM	1	119	SEAT	1	308	BOLT	1
002	MAIN FRAME	1	120	STRAP BUCKLE COVER - TOP	1	309	BOLT	1
003	DIE CAST PIVOT	1	121	STRAP BUCKLE COVER - BOTTOM	1	310	BOLT	1
004	DIE CAST PIVOT SHAFT	1	122	PLUG	1	311	BOLT	1
005	STABILIZER - FRONT	1	123	FOAM GRIP	1	312	BOLT	1
006	STABILIZER - REAR	1	124	SEAT CARRIAGE STOPPER	1	313	BOLT	2
007	REAR BRACKET	1	125	CLAMP KNOB	1	400	WASHER	1
008	AL HANDLE BAR	1	126	HEEL SUPPORT - ASSEMBLY	2	401	WASHER	12
009	SEAT CARRIAGE	2	127	HEEL SUPPORT - STOPPER	4	402	WASHER	2
010	SEAT CARRIAGE - SHAFT	2	128	HEEL PIVOT ASSEMBLY	4	403	WASHER	4
011	GUIDE ROLLER - BOLT	2	129	COVER - VENT	1	500	SCREW	1
012	GUIDE ROLLER - PLATE	2	130	PANCAKE - ALUMINUM	1	501	SCREW	32
013	FOOT REST - RIGHT	1	131	PANCAKE - SLEEVE	2	502	SCREW	8
014	FOOT REST - LEFT	1	132	STRAP SLOT TRIM	1	503	SCREW	5
015	COMPUTER ARM	1	133	BATTERY COVER	1	504	SCREW	2
016	TENSION WHEEL ASSEMBLY	1	134	POLY V <sup>W</sup> DRIVE BELT	1	505	SCREW	5
017	CLUTCH SHAFT	1	135	DRIVE PULLEY	1	600	RETAINING RING	1
018	RETURN SPRING	1	136	STRAP DRUM	1	700	TENSION CABLE	1
019	GUIDE ROLLER - SPACER	2	137	RETURN SPRING - DRUM	1	701	MOTOR <sup>with</sup> CABLE	1
020	PANCAKE - SLIDER	1	138	RETURN SPRING - COVER	1	702	MOTOR SENSOR CABLE	1
021	PANCAKE - SLIDER WHEEL	1	139	RETURN SPRING - HOLDER	1	703	COMPUTER CABLE - 6 x PIN	1
022	PANCAKE - CABLE GUIDE	3	140	FLYWHEEL FAN <sup>with</sup> MAGNETS	1	704	COMPUTER CABLE - 9 x PIN	1
023	COMPUTER ARM - PLUG	2	141	TENSION WHEEL ASSEMBLY - SPACER	1	705	PANCAKE - CABLE	1
024	COMPUTER ARM - PIVOT	2	142	GUIDE ROLLER	2	706	PANCAKE - FLYWHEEL SHAFT	1
025	COMPUTER ARM - PLUG COVER	2	143	FOOT REST TREAD	2	707	PANCAKE - SPRING	1
026	COMPUTER ARM - SPACER	2	200	NUT	9	708	SENSOR MAGNET ASSEMBLY	1
027	COMPUTER CASE NUT COVER	2	201	NUT	2	709	DRIVE STRAP ASSEMBLY	1
028	HANDLE BAR HOLDER	1	202	NUT	1	710	FOOT REST - STRAP	2
029	COVER - FRONT	1	203	NUT	1	711	CHEST BAND RECEIVER	1
030	COVER - HUB	2	204	NUT	1	712	AC ADAPTOR - CABLE	1
031	COVER - MAIN	2	300	BOLT	24	713	BATTERY CASE <sup>with</sup> CABLE	1
032	MESH	1	301	BOLT	1	714	COMPUTER	1
033	WHEEL CAP - LEFT	1	302	BOLT	2	715	AC ADAPTOR	1
034	WHEEL CAP - RIGHT	1	303	BOLT	4	800	BEARING	2
035	STANDARD CAP	2	304	BOLT	2	801	BEARING	1
036	ALUMINUM BEAM END CAP	1	305	BOLT	2	802	BEARING	2
037	SEAT CARRIAGE - COVER	2	306	BOLT	8	803	BEARING	1
038	SEAT CARRIAGE - ROLLER	4	307	BOLT	1	804		1

