

Parts List & Parts Diagram

P/N	DESCRIPTION	Qty	P/N	DESCRIPTION	Qty
A	MAIN FRAME	1	A15-5	WASHER	1
A1	MOTOR SENSOR WIRE 1200mm	1	A15-6	CLIP C15	1
A2	SENSOR WIRE 500mm	2	A16	PRESSING PIPE	1
A2-1	SENSOR WIRE 250mm	2	A16-1	BEARING 6203Z	2
A3	ELECTRONIC KNOB	1	A16-2	CLIP	1
A3-1	ELECTRONIC KNOB STICKER	1	A16-3	SPRING	1
A4	OSCILLATING AXLE BASE(L)	1	A16-4	PIPE	3
A4-1	END CAP	2	A16-5	WASHER	3
A4-2	BEARING 6905ZZ	4	A16-6	SPRING WASHER	3
A4-3	SCREW CAP	2	A16-7	SCREW	3
A4-4	SCREW M8x20	2	A17	MAGNETIC HOUSING	1
A4-5	WASHER M8x28x2T	2	A17-1	SCREW M8x52	1
A4-6	WASHER M8x16x1.2T	2	A17-2	NUT M8	1
A4-7	SPRING WASHER M8	2	A17-3	SCREW M6x65	1
A5	OSCILLATING AXLE BASE(R)	1	A17-4	NUT M6	1
A6	FRONT CONNECTING SHAFT	2	A17-5	SPRING	1
A6-1	SCREW M8x50	6	A17-6	WASHER M7x22x2.5T	1
A6-2	WASHER M8	22	A17-7	WASHER M6x18	1
A6-3	BUSH $\Phi 8(\Phi 11.9+\Phi 15)$	12	A17-8	NUT M6	1
A6-4	CLIP(R36)	12	A18	MOTOR	1
A6-5	BEARING 6201ZZ TPX	18	A18-1	SCREW	4
A6-6	BEARING SLEEVE $\Phi 42 \times 3T$	12	A18-2	TENSION CABLE	1
A6-7	NUT M8	8	A18-3	SENSOR WIRE 600mm	1
A6-8	BEARING HOUSING	12	A18-4	SENSOR WIRE HOUSING	1
A7	CRANK CONNECTING SHAFT	2	A18-5	SCREW	1
A7-1	BEARING 2203 MRB	2	A19	TURING PLATE	2
A7-2	CLIP(R40)	2	A19-1	SCREW M5x12	4
A7-3	NUT M10	2	A20	DC JACK HOUSING	1
A7-4	END CAP	1	A20-1	SCREW	2
A7-5	END CAP	1	A20-2	DC WIRE 600mm	1
A7-6	WASHER M10x19x2T	2	A21	MAIN CHAIN COVER(L)	1
A8	CRANK	2	A22	MAIN CHAIN COVER(R)	1
A9	SCREW M10x30	2	A23	SMALL CHAIN COVER(L)	1
A9-1	NUT M10	2	A24	SMALL CHAIN COVER(R)	1
A10	FLAT KEY	2	A25	END CAP	2
A11	AXLE	1	A26	OSCILLATING AXLE BASE COVER(L)	2
A11-1	WASHER M6	4	A27	OSCILLATING AXLE BASE COVER(R)	2
A11-2	NUT M6	4	A28	FRONT PEDAL SUPPORTING TUBE(UP)	2
A11-3	SCREW M6x18	4	A28-1	SCREW M8x75	2
A11-4	BEARING 6005ZZ	2	A28-2	BUSH $\Phi 12 \times \Phi 7.9 \times 49.7$	6
A11-5	CLIP	2	A28-3	SCREW M8x15	6
A12	BELT WHEEL $\Phi 350$	1	A28-4	END CAP	2
A13	MAGNETIC $\Phi 15 \times 7$	1	A29	FRONT PEDAL SUPPORTING TUBE(UNDER)	2
A14	BELT 1371mmxJ6	1	A29-1	BUMPER(+SCREW)	4
A15	FLYWHEEL (12KG)	1	A29-2	SENSOR HOUSING(UNDER)	2
A15-1	M10	2	A29-3	SENSOR HOUSING(UP)	2
A15-2	AXLE CENTER	1	A29-4	SENSOR	2
A15-3	CLIP C12	1	A29-5	SENSOR COVER	2
A15-4	BEARING 6202ZZ	2	A29-6	SCREW M4x13	4

P/N	DESCRIPTION	Qty	P/N	DESCRIPTION	Qty
A29-7	SCREW M2x6	10	G4	BUSH Φ16.98xΦ9.9x49.7	2
A29-8	SCREW M3x6	6	G5	LOWER PEDAL SUPPORTING TUBE	2
A29-9	SCREW M3x8	8	G6	SCREW M8x25	4
A30	PUSH ROD BRACKET	2	G7	PEDAL REINFORCEMENT COVER	4
A30-1	ADJUSTMENT KNOB	4	G8	SCREW M4x10	4
A30-2	ADJUSTMENT NUT	4	G9	PEDAL TUBE END CAP	2
A30-3	HANDLE	2	G10	AXLE BUSHING	4
A30-4	SCREW M8x45	2	G11	SCREW M8x20	4
A30-5	BUSH	4	G12	SPRING WASHER M8	4
A30-6	NYLON NUT M8	2	G13	WASHER M8	4
A30-7	SCREW M6x10	2	G14	BUSH	2
A30-8	SPRING	2	G15	LEFT SIDE PEDAL SUPPORTING TUBE	2
A30-9	BLOCK	2	G15-1	RIGHT SIDE PEDAL SUPPORTING TUBE	2
A30-10	SOCKET SET SCREW M4x4	2	G16	CLIP(R28)	8
A30-11	MAGNETIC HOUSING	2	G17	BEARING 6001ZZ	8
A30-12	SCREW M4x8	4	G18	WASHER	4
A30-13	SPRING	2	G19	NUT M8	4
A30-14	MAGENETIC	2	G20	PEDAL BRACKET(L)	1
A30-15	NYLON SCREW COVER M6	2	G21	PEDAL(L)	1
A30-16	HANDLE BLOCK-A	2	G22	CUSHION PAD(L)	1
A30-17	HANDLE BLOCK-B	2	G23	FRONT PEDAL COVER(L)	1
A30-18	WASHER	4	G24	PEDAL BRACKET(R)	1
B	CENTRAL SUPPORTING TUBE	1	G25	PEDAL(R)	1
B1	SENSOR WIRE 650mm	1	G26	CUSHION PAD(R)	1
B2	ELECTRONIC KNOB WIRE 700mm	1	G27	FRONT PEDAL COVER(R)	1
B3	LED SENSOR WIRE 350mm	1	G28	SCREW M6x12	12
B4	HANDLE PULSE WIRE 850mm	2	G29	SCREW M4x20	6
B5	LED SENSOR	1	G30	WASHER M8x28x2.0T	4
B6	HANDLE PULSE	2	H1	HANDLE BAR(L)	1
B6-1	SCREW	4	H2	HANDLE BAR(R)	1
B7	SPONGE HDR 200mm	2	H3	SPONG HDR 655mm	2
B8	END CAP	2	H4	HANDLE BAR END CAP	2
B9	END CAP	1	I1	BOTTLE HOLDER	1
C	CONSOLE	1	I2	BOTTLE	1
C1	SCREW M5x10	4	J1	SCREW M8x15	19
D	CONNECTING TUBE	1	J2	WASHER M8x16x1.2T	27
E	REAR STABILIZER	1	J3	SCREW M10x75	2
E1	END CAP	2	J4	WASHER M10x19x2.0T	4
E2	NUT	2	J5	NUT M10	2
E3	ADJUSTED END Φ50	2	J6	SCREW M8x70	4
F	FRONT STABILIZER	1	J7	NUT M8	4
F1	END CAP	2	J8	HANDLE BAR SCREW	6
F2	FIX CUSHION Φ50 TPR	2	J9	HANDLE BAR SCREW	6
F3	WASHER M6x19x2T	2	J10	BOTTLE HOLDER SCREW	2
F4	SCREW M5x16	2	J11	SCREW M4x20	6
F5	TRANSPORTATION WHEEL	2	J12	NUT M4	8
F6	SCREW M8x40	2	J13	SCREW M4x45	2
F7	NUT M8	2	J14	SCREW M4x25	7
G1	PEDAL SUPPORTING TUBE(L)	1	J15	SCREW M4x18	10
G2	PEDAL SUPPORTING TUBE(R)	1	J16	SPRING WASHER M8	13
G3	BEARING 6003ZZ	4	K	ADAPTOR	1



