





Control Surface Settings

Control surface mode: Mackie Control Extender

5

MIDI input: iCON iCreativ V1.01

6

MIDI output: iCON iCreativ V1.01

7

Surface offset (tracks): 0

Size tweak: 9 (leave at 9 unless you know what you're doing)

Ignore fader moves when fader is not being touched

8

Map F1-F8 to go to markers

9

OK

Cancel

- VU Meters/Faders
- Theme Editor
- Editing Behavior
- Envelope Display
- Automation
- Mouse
- Mouse Modifiers
- MIDI Editor
- Media
- MIDI
- Video/REX/Misc
- Plug-ins
- Compatibility
- VST
- ReWire/DX
- ReaScript
- ReaMote
- Control Surfaces

Find