

keyscaper[®]
fan gear

DJ Style Headphones


Product Manual
Version 1.0

THANK YOU!

Thanks for choosing Keyscaper!

Please read the following manual carefully to ensure you get the most out of your DJ Style Headphones.

Product Guide:



Index:

Usage & About

Page
3

Usage & About:

These DJ Style headphones are plug and play, no batteries or installation needed.



② Swivel Hinge

The swivel hinge allows you to manipulate the headphones for comfort and some compactability for travel.

① AUX Port


The auxiliary port is located on the bottom of the right headphone. This allows you to connect the headphones to your device

③ Microphone

The microphone gives you a hands-free option for devices that support it.

④ Pause/End Call

The small button allows you to pause your music or end a phone call.



Device End

Headphone End