



MyWindFit Meter (weather meter)

The MyWindFit Heart Monitor is a wireless Bluetooth meter that continuously monitors your heart rate during your activity. The MyWindFit app has a unique function that also measures and records your resting heart rate. MyWindFit Analytics uses these values to determine how difficult your routine was by calculating your training zone effort (insert link).

Components



1 Front



2 Back



Assembly

The MyWindFit Meter comes fully assembled. To activate the battery, remove the tab as shown below and discard.



Turn on and Sync with MyWindFit mobile app

Open the MyWindFit mobile app and press the front button on the meter. The meter will try to sync for 30 seconds after the button is pressed, if no sync is established, the meter turns off.



Replacing battery






Cleaning

The weather meter may become dirty after repeated use. The recommend cleaning procedure are as follows.

The weather meter cover can be removed from the meter and washed with warm soapy water. Please dry thoroughly before installing the cover back over the meter. The white weather shield of the meter may also be whipped with a wet towel or cotton swab.



To clean the weather meter “fan” blades, use a wetted cotton swab and gently remove any dirt buildup from each of the blades.





Troubleshooting

Symptom	Possible Solutions
<p>MyWindFit meter will not connect to the MyWindFit app.</p>	<ol style="list-style-type: none"> 1) Verify that your Android phone is running software 4.3 or higher. <ol style="list-style-type: none"> a. Copy this link or search this in your phones internet browser: http://whatismyandroidversion.com/ 2) Verify that Bluetooth is enabled on your smart device. 3) Open the MyWindFit app and navigate to the Diagnostics/Bluetooth screen. 4) Press the button located on the front of the meter. If the battery is good, the meter will show on the Bluetooth scan screen. <div data-bbox="954 676 1295 989" data-label="Image"> </div> 5) If the meter is not displayed on the scan screen, remove the black rubber cover and press the clear button. If the battery is good, this button will flash a blue light for 30 seconds. 6) If the blue light does not turn on, replace the CR2450 battery and retest <div data-bbox="899 1239 1295 1675" data-label="Image"> </div>
<p>SEE THE FAQ SECTION OF THE MYWINDFIT WEBSITE FOR MORE</p>	