

“Tier 3 generator Controls” 3.5” x 5”, our part # 3003210

To start the generator:

1. Pull the emergency stop button out.
2. Turn the battery disconnect switch on the rear of the generator to the ON position
3. Move to upper deck to the generator main control panel.
4. Push the “light” button once (if the Controller Display does not turn ON automatically)
5. Push the “reset” button once.
6. Push the “manual” button once.
7. Push the “start” button to start the generator.
Generator has a warm-up, which is approximately 10 minutes or until the coolant reaches a temperature of 100°. At that time, the generator will automatically switch into operating RPM mode.

To shut down the generator:

1. Push the “stop” button on the main control panel once to enter cool-down mode.
2. Wait for engine to cool down, and will shut off automatically
3. Push the emergency stop button
4. Wait 45 seconds*
5. Turn the battery disconnect switch to the OFF position.

* The sequence and 45-seconds wait time are critical for proper operation