Kindle (1st Generation) Quick-Start Guide



© 2018 Amazon.com, Inc. or its affiliates. All rights reserved.

Kindle (1st Generation) Quick-Start Guide

- Turn on Your Kindle
- Use the Select Wheel
- Register Your Kindle for the First Time
- Learn More About Kindle (1st Generation)

Turn on Your Kindle

To turn on your Kindle, push the power switch on the back of your Kindle up into the **ON** position. You may need to plug in your Kindle and charge the battery.



Use Your Kindle's Select Wheel

Your Kindle's Select wheel scrolls the silver cursor up and down the page. To select a point on a page, scroll the cursor to the selection point and push the Select wheel inwards once.



© 2018 Amazon.com, Inc. or its affiliates. All rights reserved.

Register Your Kindle for the First Time

Your Kindle must be registered to your Amazon.com account to use many of the features, such as purchasing content. If you received your Kindle a gift and it is currently registered to a different user or Amazon.com account, you can **Deregister it** in your Kindle settings. Then register Kindle to your own Amazon.com account.

To remove an existing registration:

1. Move the wireless switch on the back of your Kindle to **ON**.
2. Press the **Home** key.
3. Scroll to **Menu** and press the select wheel.
4. Select **Settings** from the menu.
5. Scroll to the **Account Name** section and select **Deregister**.
6. Select **OK** from the confirmation screen or select **Cancel** if you want to cancel the process.

   The account name turns blank and the Register option appears when deregistration is successful.

To register your Kindle to your Amazon.com account:

1. Move the wireless switch on the back of your Kindle to **ON**.
2. Press the **Home** key.
3. Scroll to **Menu** and press the select wheel.
4. Select **Settings** from the menu.
5. Scroll to the **Account Name** section and select **Register**. If an account name already appears, select **Deregister**.
6. Enter your Amazon.com user name and select **Done**.
7. Enter the password for your Amazon.com account and select **Done**.

   The account name appears when registration is successful.

Learn More About Kindle (1st Generation)

You can find many answers to your questions in the on-device user guide found within your Settings menu.

© 2018 Amazon.com, Inc. or its affiliates. All rights reserved.