

FREEMOTION[®] E P I C[™]


Olympic Decline Bench

OWNER'S MANUAL

Model No. GZFW2154.3

Serial No. _____

Write the serial number in the space above for future reference.




QUESTIONS?

At FreeMotion Fitness, we are committed to providing complete customer satisfaction. If you have questions, see HOW TO CONTACT CUSTOMER CARE on the back cover of this manual.

CAUTION

Read all precautions and instructions in this manual before using this equipment. Save this manual for future reference.



Visit our website at

www.freemotionfitness.com

TABLE OF CONTENTS

IMPORTANT PRECAUTIONS	2
BEFORE YOU BEGIN	3
ADJUSTMENT	4
MAINTENANCE	5
PART LIST	6
EXPLODED DRAWING	7
HOW TO CONTACT CUSTOMER CARE	Back Cover

IMPORTANT PRECAUTIONS

⚠ WARNING: To reduce the risk of serious injury, read the following important precautions before using the strength equipment.

1. Read all instructions in this manual before using the strength equipment. Use the strength equipment only as described in this manual.
2. Keep the strength equipment indoors, away from moisture and dust. Do not put the strength equipment in a garage or covered patio, or near water.
3. Use the strength equipment only on a level surface. Cover the floor beneath the strength equipment to protect the floor.
4. It is the owner's responsibility to ensure that there is enough space around the strength equipment for the intended exercise. Do not crowd the strength equipment.
5. Using the three 9/16" anchor holes to provide maximum stability, anchor the strength equipment to the floor where required or whenever possible.
6. Make sure all parts are properly tightened before each use of the strength equipment. Replace any worn parts immediately.
7. All users of the strength equipment should be instructed to report any injury or strength equipment irregularity to the facility staff immediately.
8. It is the responsibility of the owner to ensure that all users of the strength equipment are adequately informed of all precautions, have read and understood all warning and caution labels, and are informed of how to use the strength equipment properly.
9. Keep children under age 12 and pets away from the strength equipment at all times.
10. The strength equipment is designed to support a maximum user weight of 350 pounds (159 kg), and a maximum total weight of 1,150 pounds (522 kg). Do not use the strength equipment with more than 800 pounds (363 kg) of weight, including a barbell. Note: The strength equipment does not include a barbell or weights.
11. Always wear athletic shoes for foot protection while exercising.
12. Keep hands and feet away from moving parts. Do not lean on or rest your hands on the strength equipment when it is in use.
13. Always exercise with a partner. Your partner should be ready to catch the barbell if you cannot complete a repetition.
14. If you feel pain or dizziness while exercising, stop immediately and begin cooling down.

⚠ WARNING: Before beginning this or any exercise program, consult your physician. This is especially important for persons over the age of 35 or persons with pre-existing health problems. Read all instructions before using. FreeMotion Fitness assumes no responsibility for personal injury or property damage sustained by or through the use of this product.


BEFORE YOU BEGIN

Thank you for selecting the FREEMOTION® EPIC™ OLYMPIC DECLINE BENCH strength equipment. The strength equipment is designed to help develop the major muscle groups of the upper body. Whether your goal is to tone your body, build dramatic muscle size and strength, or improve your cardiovascular system, the strength equipment will help you to achieve the specific results you want.

For your benefit, read this manual carefully before using the strength equipment. If you have questions

after reading this manual, please see HOW TO CONTACT CUSTOMER CARE on the back cover of this manual. To help us assist you, note the product model number and serial number before contacting us. The model number is GZFW2154.3. The serial number can be found on a decal attached to the strength equipment (see the front cover of this manual).

Before reading further, please review the drawing below and familiarize yourself with the parts that are labeled.




ADJUSTMENT

This section explains how to adjust the strength equipment for exercising. Make sure all parts are properly tightened each time the strength equipment is used. Replace any worn parts immediately.

STORING WEIGHTS

Store unused weights on the storage bars.

⚠ WARNING: Each storage bar can hold up to 150 pounds (68 kg). Do not place more than a total of 800 pounds (363 kg), including a barbell (not included), on the racks and the storage bars. Always place the same amount of weight on each end of your barbell.



ADJUSTING THE LEG FRAME

To adjust the leg frame, first pull the pop pin out as far as it will go. Slide the leg frame into or out of the base, and then engage the pop pin into the leg frame.

MAINTENANCE

For optimal performance of the strength equipment and to reduce the chances of injury to users, you must perform preventive maintenance on a regular basis. Instruct all personnel to perform the procedures described in this section. Personnel must also record and report any accident. To maintain the strength equipment's warranty, use only FREEMOTION EPIC parts for repair or replacement. If there are any questions or concerns, see HOW TO CONTACT CUSTOMER CARE on the back cover of this manual.

DAILY MAINTENANCE

Upholstery and Frame—General Cleaning

1. Clean the strength equipment using a soft cloth dampened with a light solution of mild soap and warm water. If necessary, use a soft bristle brush with the cleaning solution.
2. Rinse the area thoroughly using a soft cloth dampened with clean water. Dry thoroughly.

Upholstery—Difficult Stains

1. Spray the stain with a non-abrasive household cleaner such as FORMULA 409® cleaner, SIMPLE GREEN®, or a similar product. Rub the stained area gently and let the cleaning solution sit for a few minutes.
2. Rinse the area thoroughly using a soft cloth dampened with clean water. Dry thoroughly.
3. Repeat these steps if necessary using a soft bristle brush.

Optional Method for Difficult Stains

1. Rub the stained area gently using a soft cloth dampened with rubbing alcohol.
2. Rinse the area thoroughly using a soft cloth dampened with clean water. Dry thoroughly.

CAUTION: When using any cleaning product, try it first in an unnoticeable place to ensure that there is no damage to the material. Follow the directions and the safety precautions of the manufacturer of each cleaning product used. FreeMotion Fitness and its vendors cannot be held liable for damage or injuries resulting from the use or misuse of cleaning products.

Important: Do not use abrasive cleaners, which may scratch the strength equipment. Strong cleaners and abrasives will damage decals; use caution around decals. Do not use solvents such as lacquer thinner, kerosene, gasoline, or similar liquids.

WEEKLY MAINTENANCE

Hardware

Check all nuts and bolts and tighten them as required.

Important: All FREEMOTION EPIC cushions have dense plywood supports with tee-nuts that are used to bolt the cushions to the strength equipment. Because the tee-nuts are held by the plywood, they will not withstand the torque that standard nuts and bolts will. When tightening the bolts securing a cushion, turn them only until they are snug and the cushion does not move or feel loose. Overtightening may strip the tee-nuts from the plywood and make it impossible to remove the cushion in the future.

PART LIST—Model No. GZFW2154.3

R0207A

If replacement parts are needed, or if parts are missing or damaged, see HOW TO CONTACT CUSTOMER CARE on the back cover of this manual.

Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Base	16	4	Bumper Ring
2	1	Left Frame	17	1	5/16" Washer
3	1	Right Frame	18	8	1/2" x 3 1/2" Button Screw
4	1	Right Upright	19	3	3/8" x 4" Non-patch Screw
5	1	Left Upright	20	2	1/2" x 5" Bolt
6	1	Leg Frame	21	2	1/2" Nylon Locknut
7	1	Seat	22	1	Pop Pin
8	2	Knee Pad	23	2	1/2" x 2" Button Screw
9	2	Shin Pad	24	4	3/8" x 1" Non-patch Screw
10	1	Pad Tube	25	1	3/8" x 1 3/4" Button Screw
11	2	Bearing Tube	26	1	Seat Cover
12	2	Clamp Collar	27	2	Long Wear Cover
13	2	Round Outer Cap	28	2	Short Wear Cover
14	4	Bushing	29	10	Wear Cover Screw
15	2	Storage Bar	*	-	Owner's Manual

Note: Specifications are subject to change without notice. See the back cover of this manual for information about ordering replacement parts. *These parts are not illustrated.

R0207A



HOW TO CONTACT CUSTOMER CARE

If you have questions after reading this manual, or if you require assistance, please contact Customer Care at the address and phone number listed below. Please be prepared to give the following information:

- the MODEL NUMBER of the product (GZFW2154.3)
- the NAME of the product (FREEMOTION EPIC OLYMPIC DECLINE BENCH strength equipment)
- the SERIAL NUMBER of the product (see the front cover of this manual)

When ordering replacement parts, please also give the KEY NUMBER and DESCRIPTION of the part(s) (see the PART LIST and the EXPLODED DRAWING on pages 6 and 7).

Customer Care: 1-800-201-2109, Monday–Friday, 8 a.m.–5 p.m. Mountain Time
FreeMotion Fitness, Inc. • 1096 Elkton, Suite 600 • Colorado Springs, CO 80907

FREEMOTION is a registered trademark of ICON IP, Inc.