



IMAGE

FLAT TO INCLINE BENCH

WHHY 3312





PARTS LIST

REF NO.	PART NO.	QTY	DESCRIPTION
1	3312-01	1	BASE
2	3312-02	1	FRONT LEG
3	3312-03	1	REAR LEG
4	3312-04	2	BACK SUPPORT
5	3312-05	2	SEAT SUPPORT
6	3312-06	1	BACK PAD
7	3312-07	1	SEAT PAD
8	3312-08	7	2" END PLUG
9	3312-09	1	KNOB BOLT
10	3312-10	3	L - PINS
11	3312-11	2	3/8" - 16 X 2 1/2" BOLTS
12	3312-12	8	3/8" - 16 X 3/4" BOLTS
13	3312-13	16	3/8" WASHER
14	3312-14	5	3/8" HEX NUT
15	3312-15	3	3/8" - 16 X 3" BOLTS

TO ORDER REPLACEMENT PARTS CONTACT:

IMAGE INC.
3670 PARKWAY LANE SUITE J
HILL IARD, OH 43026


TOOLS REQUIRED 2 - adjustable wrenches

- 1) Insert the Front Leg (2) and the Rear Leg (3) into the Base (1). Secure it with the L-Pin (10) in the front and the Bolts (11) in the rear. Thread the Thumbscrew (9) into the weld nut on the front of the Base (1).
- 2) Slip the Back Support (4) into position by placing it below the top horizontal tube of the Base(1). Pull it up until the holes in the angle line up with the 2nd set of holes in the tube as shown. Secure this with the Bolt (15) and fasteners pictured.
- 3) Fasten the Seat Supports (5) to the Base (1) as shown. Make sure the adjustment bars point towards the front. Center the two pads onto both supports and allow for pivotal movement. Secure with the Lag Screws (12) and washers (13).
- 4) Insert the L-Pins (10) where shown. Push the End Plugs (8) into the tube openings on the legs and back of the Base (1). Tighten all bolts securely before using.
- 5) To use the incline feature of the Front Leg (2), you must do the following. Unbolt the Rear Leg (3) and swing it around so that the feet extenders point to the front. Fasten the Base (1) with the turned around Rear Leg (3), and tighten before use.

IMAGE 3312

PERSONAL FITNESS SYSTEM

FLAT INCLINE/DECLINE BENCH



MODEL NO. IM3312 ©1994 IMAGE, INC. Specifications subject to change. REV.6/14/94