

REZUR INPUT LIST

CH	INST.	MIC	STAND
1	KICK IN	BETA 91	
2	KICK OUT	BETA 52, D 112	SHORT BOOM
3	SNARE TOP	BETA 57, SM 57	CLAMP L.P.
4	SNARE BOT	BETA 57, SM 57	CLAMP L.P.
5	TOM 1	e604, D2	CLAMP L.P.
6	TOM 2	e604, D2	CLAMP L.P.
7	FLOOR TOM 1	e604, MD-421, D4	CLAMP L.P.
8	FLOOR TOM 2	e604, MD-421, D4	CLAMP L.P.
9	OH L	U87, C414, C214, SM 81	MED BOOM
10	OH R	U87, C414, C214, SM 81	MED BOOM
11	HI-HAT	SM 81	SHORT BOOM
12	BASS D.I.	ACTIVE D.I.*	
13	GUITAR TOP	e906, e609, SM57	SHORT BOOM
14	GUITAR BOTTOM	e906, e609, SM57	SHORT BOOM

15	ACOUSTIC 1	ACTIVE D.I.*	
16	ACOUSTIC 2	ACTIVE D.I.*	
17	TRACKS L	ACTIVE D.I.*	
18	TRACKS R	ACTIVE D.I.*	
19	CLICK	ACTIVE D.I.*	
20	SLATE	ACTIVE D.I.*	
21	KEYS L	ACTIVE D.I.*	
22	KEYS R	ACTIVE D.I.*	
23	SAX	SM 57	MED BOOM
24	VOX I	SM 57*	MED BOOM
25	VOX II	WIRELESS SM 58 *	ROUND BASE*
26	VOX III	SM 58	MED BOOM
27	PAD LOW	ACTIVE D.I.	
28	PAD HIGH	ACTIVE D.I.	
29	ROOM L	QTC30*	TALL BOOM
30	ROOM R	QTC30*	TALL BOOM

*Provided by artist.

Andres Sosa
Production Manager

rezurmusic@gmail.com
843.422.8004

STAGE PLOT

