
TR8 PR0

Assembly Guide





IMPORTANT: As there are different versions of each rig depending on your region, please ensure that you are using the correct instruction set. The part number below should match the part number labeled on your box

TR8-06-B



TABLE OF CONTENTS

- 3 Symbol Legend
- 4 Part list
- 5 Assembly Notes
- 7 TR8-06-B Assembly Instructions
 - 11 GT/Rally seat installation
 - 13 Recliner seat installation
 - 17 Monitor Stand
 - 19 DD Wheel Mount



IMPORTANT: As there are different versions of each rig depending on your region, please ensure that you are using the correct instruction set. The part number below should match the part number labeled on your box



IMPORTANT: Due to the nature of cut aluminium profile, some metal shavings may still be present after our extensive QA cleaning process. We recommend that boxes and packaging is opened on a hard floor.



NOTE: Some screws and washers are pre-installed. These will be part of the parts list and will need to be loosened and reattached according to the instructions.



Two people needed



Tighten hardware



Leave hardware loose for adjustment



Make Adjustment



Break tab off Corner bracket CB1



Safety glasses needed



Attention / Priority



Reserve for following step





Mirrored Components (Same on both sides)


TR8-06-B PARTS LIST


Part #	Description	QTY	Check
TF-TR8-F	Tube Frame, TR8, Front Section	1	
TF-TR8-B	Tube Frame, TR8, Back Section	1	
TF-TR8-L	Tube Frame, TR8, Left Section	1	
TF-TR8-R	Tube Frame, TR8, Right Section	1	
SB-M8-15	Screw (Button), M4x15	32	
SH-M8-16	Screw (Hex), M8x16	4	
SH-M6-16	Screw (Hex), M6x16	8	
SH-M8-20	Screw (Hex), M8x20	4	
SB-M8-65	Screw (Button), M8x65	2	
SH-M5-15	Screw (Button), M5x15	8	
SH-M8-12	Screw (Hex), M8x12	6	
TF-TR8-SA	Tube Frame, TR8, Shifter Assembly	1	
TF-SB	Tube Frame, Shifter Block	2	
TF-TR8-MS	Tube Frame, TR8, Monitor Strut	1	
TF-TR8-WM	Tube Frame, TR8, Wheel Mount	1	
SS-01	Seat Slider	0	
WF-M8	Washer (Flat), M8	18	
WL-M8	Washer (Lock), M8	4	
WC-M8	Washer (Curved), M8	12	
WF-M6	Washer (Flat), M6	8	
WL-M6	Washer (Lock), M6	8	
WM-WM4	Wheel Mount, TR80-NWM4 Assembly	1	

^{*} NOTE: Extra hardware may be included as spare parts
















The handle screws (SL-M8-20 & SL-M8-25) are ratcheted to allow for tightening and loosening when space for rotation is limited. Simply pull the handle out and turn handle into position and push handle back in to engage thread.




















3











SH-M8-20 x4


WF-M8 x4

TF-TR8-WM X1

WM-WM4 x1

NOTE: Some screws and washers com pre-installed. These will be part of the parts list and will need to be loosened and reattached according to the instructions.














SH-M6-16 x8


WL-M6 x8


WF-M6 x8

NOTE: Some screws and washers com pre-installed. These will be part of the parts list and will need to be loosened and reattached according to the instructions.










0 0

TRANCA.

40-04










NOTE: Some screws and washers com pre-installed. These will be part of the parts list and will need to be loosened and reattached according to the instructions.







OPTIONAL: Rally/GT Seat Assembly








OPTIONAL: Recliner Seat Assembly















OPTIONAL: TR8 Monitor Stand



Part #	Description	QTY	Check
BOX #: TR-TR8-SIN	G		
SH-M8-10	Screw (Hex), M8x10	8	
SF-M8-16	Screw (Flat), M8x16	4	
WF-M8	Washer (Flat), M8	8	
NF-M8	Nut (Flange), M8	4	
BP-IS	Bracket (Plate), Integrated Single Monitor Mount	4	
BM-IS	Bracket (Monitor), Integrated Single Monitor Mount	2	

^{*} NOTE: Extra hardware may be included as spare parts

TR-TR8-SING


















OPTIONAL: Direct Mount for Simucube, Simucube 2, VRS, Simagic, MIGE





Part #	Description	QTY	Check
BOX #: TR8-DDBR			
SH-M8-25	Screw (Hex), M8x25	4	
WF-M8	Washer (Flat), M8	8	
WL-M8	Washer (Lock), M8	8	
NF-M8	Nut (Flange), M8	4	
WM-DD-BR	Wheel Mount, DD Brackets	2	
SH-M8-16	Screw (Hex), M8x16	4	
BOX #: TR80-NWMDD			
SH-M8-20	Screw (Hex), M8x20	4	
SH-M8-25	Screw (Hex), M8x25	4	
WF-M8	Washer (Flat), M8	4	
SH-M5-10	Screw (Button), M5x10	2	
WF-M5	Washer (Flat), M5	2	
WM-DD	Wheel Mount, Direct Drive	1	


^{*} **NOTE**: Extra hardware may be included as spare parts


















NOTE: Use mounting screws provided with wheelbase if necessary





FINISHED



Share your build online and tag us to be featured!





