



# **GLOWSTICK MARKER INSTRUCTIONS**



1. To activate glow, bend till tube snaps, then shake for 30 seconds

3. Keep drawing while keeping the point pressed down




2. Remove cap, point tip straight down, and press into drawing surface

NOTE: When tip is pressed down for the first time, excess solution may flow out


- For best results, draw on included Felt Sticker sheets - see instructions on opposite side. Marker can also be used on other surfaces, such as paper and cardboard

## **LANYARD INSTRUCTIONS**

To use the Glow Marker as a pendant:



1. Insert one end of the lanyard through the loop at end of cap



2. Tie the ends securely as shown in picture

NOTE: Lanyard will break if pulled, to prevent choking

## **CAUTION AND SAFETY INSTRUCTIONS**

**WARNING: GLOW MARKER MUST BE USED FOR DRAWING WITHIN 1 MINUTE OF ACTIVATION!**

1. Keep Glow Marker in original bag until ready to use
2. Inner stick contain glass - DO NOT attempt to puncture or cut the outer surface of the marker
3. Avoid contact with skin for extended period of time
4. After play, wash hands with soap and water
5. Glow Marker will stain most surfaces, including fabrics and walls
6. May damage plastic surfaces: when exposed, immediately remove residue with damp cloth
7. Felt sticker should not be placed directly on skin, or on surfaces that may be damaged by adhesive back

**EASY CLEANUP:** To remove residue or spills, simply wipe clean with a damp cloth

Glow Stick Marker glows up to 6 hours - One time use