

IMAGE™ 3302

PERSONAL FITNESS SYSTEMS

OLYMPIC WIDTH

Full olympic width rack allows correct hand spacing on bar and provides added safety.

ADJUSTABLE INCLINE AND RACK

Adjustable backrest allows flat, incline, & decline work. Adjustable rack height ensures proper positioning & allows uprights to double as a squat rack.

DIP HANDLES

Dip handles provide an excellent workout for triceps, shoulders & chest.

LEG DEVELOPER


For leg extensions and horizontal leg curls.

QUALITY CONSTRUCTION

Heavy-duty square steel tubing for a sturdy frame, high density foam covered in durable vinyl.

OPTIONAL ACCESSORIES

Lat tower with high & low pulley and adjustable arm curl attachment.



MODEL NO. [REDACTED]

©1994 IMAGE, INC.

Specifications subject to change.

REV. 1/21/94

ASSEMBLY INSTRUCTIONS FOR IMAGE BENCH

- 1) Insert the Plug (27) before slide the Bench Sleeve (12) over the top tube of the Bench Support Frame (2) as shown.
- 2) Insert the Adjusting "T" (25) into the Bench Support Frame (2).
- 3) Stand the Upright (1) on its feet. Attach the Bench Support Frame (2) to the upper and lower brackets on the Upright using two 2 3/4" bolts (22), with washers (17) and nuts (13).
- 4) Insert the Leg Curl Neck (5) into the Bench Support Frame (2) as shown. Slip the Leg Curl Support (4) between the bars of the Leg Curl Neck (5). Attach this with the 2 1/4" shoulder bolt (22), and nut (13). Next, slide the Leg Curl Tubes (8) through the end holes of the Leg Curl Support allowing 6 5/8" on either side of the tubes. Push the roller pads (14) onto the tubes. Lock in place with the Push Nuts (18). Attach the Rubber Bumper (19) to the bottom of the Support Frame (2) where it makes contact with the Leg Caul.
- 5) Fasten the Back Pad (11) and the Seat Pad (10) to the Bench Sleeve (12) using the 3/4 bolts (24).
- 6) Insert the Saddle Posts (3) into the vertical Tubes of Upright (1). Note: the handles are to be kept to the rear. Add the Foam Crips (20) to the handles.
- 7) Drop the Height Adjustment Bar (7) onto the brackets on the vertical tubes of the Upright (7).
- 8) Snap the 2" End Plug (15) into the ends of the tubes on the Upright (1) and the Adjusting "T" (25). Push the 1 3/4" End Plugs (16) into the Leg Curl Unit (4 and 5). Thread the 3/8 Thumbscrew (21) into the Bench Support Frame (2) as shown.

PARTS LIST


REF. NO.	PART NO.	QTY	PART DESCRIPTION
1	3302-01	1	WIDE UPRIGHT
2	3302-02	1	BENCH SUPPORT FRAME
3	3302-03	2	SADDLE POST
4	3302-04	1	LEG CURL SUPPORT
5	3302-05	1	LEG CURL NECK
6	3302-06	2	LOCKING PIN
7	3302-07	1	ADJUSTMENT BAR
8	3302-08	2	LEG CURL TUBE
9	3302-09	4	L - PIN
10	3302-10	1	SEAT PAD
11	3302-11	1	BACK PAD
12	3302-12	1	BENCH SLEEVE
13	3302-13	4	HEX NUT 3/8"
14	3302-14	4	FOAM ROLLER PAD
15	3302-15	10	2" PVC END PLUG
16	3302-16	4	1 3/4" PVC END PLUG
17	3302-17	2	3/8" WASHER
18	3302-18	4	PUSH NUT
19	3302-19	1	RUBBER BUMPER
20	3302-20	2	FOAM GRIP
21	3302-21	2	THUMBSCREW 3/8"
22	3302-22	4	3/8" - 16 X 2 3/4" BOLT
23	33-2-23	1	1/2" - 12 X 4 1/2" BOLT
24	3302-24	4	3/8" - 16 X 3/4" BOLT
25	3302-25	1	ADJUSTING "T"
26	3302-26	1	HEX NUT 1/2"
27	3302-27	2	2 3/8" X 1 3/4" PVC PLUG


TO ORDER REPLACEMENT PARTS CONTACT:

IMAGE INC.
3670 PARKWAY LANE SUITE J
HILL IARD, OH 43026



**WIDE COMBO BENCH
WHHY 3302**





IMAGE

WIDE COMBO BENCH WHHY 3302

