

Before You Begin

Thank you for purchasing the durable and stylish Dumbbell Rack and Weights. The Dumbbell Rack accommodates up to ten dumbbells to organize your workout area and to provide convenient access to your dumbbells.

For your safety and benefit, please read this manual before using the Dumbbell Rack and Weights. If you have questions after reading this manual, or if you need to order replacement parts, please call Customer Service toll-free at **1-800-288-4802**, Mon.–Fri., 6 a.m.–6 p.m. Mountain Time (except on holidays).


Limited Warranty

ICON Health & Fitness, Inc. (ICON) warrants this product to be free from defects in workmanship and material, under normal use and service conditions, for a period of ninety (90) days from the date of purchase. This warranty extends only to the original purchaser. ICON's obligation under this warranty is limited to replacing or repairing, at ICON's option, the product at one of its authorized service centers. All products for which warranty claim is made must be received by ICON at one of its authorized service centers with all freight and other transportation charges prepaid, accompanied by sufficient proof of purchase. All returns must be pre-authorized by ICON. This warranty does not extend to any product or damage to a product caused by or attributable to freight damage, abuse, misuse, improper or abnormal usage, or repairs not provided by an ICON authorized service center, products used for commercial or rental purposes, or products used as store display models. No other warranty beyond that specifically set forth above is authorized by ICON.

ICON is not responsible or liable for indirect, special or consequential damages arising out of or in connection with the use or performance of the product or damages with respect to any economic loss, loss of property, loss of revenues or profits, loss of enjoyment or use, costs of removal, installation or other consequential damages of whatsoever nature. Some states do not allow the exclusion or limitation of incidental or consequential damages. Accordingly, the above limitation may not apply to you. The warranty extended hereunder is in lieu of any and all other warranties and any implied warranties of merchantability or fitness for a particular purpose is limited in its scope and duration to the terms set forth herein. Some states do not allow limitations on how long an implied warranty lasts. Accordingly, the above limitation may not apply to you.

This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

ICON Health & Fitness, Inc.
1500 S. 1000 W., Logan, UT 84321-9813



⚠ WARNING: To reduce the risk of serious injury, read the following precautions before using the tower.

1. **Inspect and tighten parts regularly. Replace worn parts immediately.**
2. **Keep children under the age of 12 and pets away from the rack at all times.**
3. **The rack is for home use only. Do not use the rack in a commercial, rental, or institutional setting.**
4. **The rack is designed to support a maximum of 56 pounds of weights.**
5. **Locate the warning decal on the rack, and read the warnings before using the rack.**
6. **Use the rack only on a level surface. Cover the floor beneath the rack to protect the floor.**
7. **Put the heaviest weights on the bottom of the rack.**

Assembly Instructions


Note: Some parts may have been pre-assembled. If a part is not in the parts bag, check to see if it has been pre-assembled.

1. Orient the Side Tubes (2) as shown at the right, with the indicated holes facing upward. Attach the Side Tubes to the Base Tube (1) with two Button Bolts (3) and two Nylon Locknuts (4).
2. Press the Endcaps (6) onto the ends of the Base Tube (1) and Side Tubes (2).
3. Orient the Towers (5) as shown. Press the Towers together.
4. Attach the tower assembly to the base assembly with four Screws (8) as shown.
5. Press the Tower Cap (7) into the top of the Towers (5).

Ordering Replacement Parts

To order replacement parts, call our Customer Service Department toll-free at 1-800-288-4802, Monday through Friday, 6 a.m. until 6 p.m. Mountain Time (except on holidays). To help us assist you, please be prepared to provide the KEY NUMBER and DESCRIPTION of the part(s) (see the Exploded Drawing/Part List).

Exploded Drawing/Part List



Key No.	Qty.	Description
1	1	Base Tube
2	2	Side Tube
3	2	Button Bolt
4	2	Nylon Locknut
5	2	Tower
6	4	Endcap
7	1	Tower Cap
8	4	Screw