










60401 - 60402 Master/Slave IR Locators

The 60401 Master Locator & the 60602 Slave Locators generate a code with IR (Infrared) light that is received by Actall's PALS® 9000/L2L Personal Mobile Transmitters (PMT) this information is then transmitted RF (Radio Frequency) into the Crisis Controller® software. The code is used to identify the alarm location or zone from which it originated. The IR Locators operate on localized power only and do not require any data runs of wiring to operate. IR Locator can also be used for the Guard Tour option in the Crisis Controller® software. IR Locators can be easily programmed with a unique ID code. Stainless steel face plates with a bubble lens configuration for increased IR dispersion and tamper proofing. The 60402 is used in conjunction with the 60401 to increase the IR coverage.



Features & Benefits

-  Generates unique ID code for zoning reliable infrared light
-  65,000+ different locations or codes available
-  Flush or surface mount in standard 2 gang electrical boxes
-  Designed for small or large areas for increased IR dispersion
-  Easy installation
-  Stainless steel face plates for high security applications (*protective wire guard available*)
-  Compatible with Crisis Controller® software for the Guard Tour option
-  High and low range settings to tailor specific coverage needs
-  Used in combination to increase the IR coverage area

Specifications

DIMENSIONS

Height: 4.5" Width: 2.75" Depth: 1.5"

CIRCUIT BOARD

Height: 2" Width: 2" Depth: 1.25"

WEIGHT

5 oz.

POWER REQUIREMENTS

12-18 VDC, 300 mA power supply



Accurate
Location



24/7
Support



Affordable
System



Optimize
Workflow



Improve
Safety



Valuable
Data

